



Великий склад запчастин, доставка на замовлення.

<https://horeca-service.net>

[+38 \(093\) 346-26-03](tel:+380933462603)

PART NO	DESCRIPTION
254/CSA50/035	Side Panel Model DR20
254/CSA50/036	Side Panel Model DR30
254/CSA50/037	Frame and Side Panels Model DR50; Gas and electric
254/CSA50/050	Frame and Side Panels Model DR50; Steam
254/CSA50/045	Frame and Side Panels Model DR75; Gas and electric
254/CSA50/052	Frame and Side Panels Model DR75; Steam
254/TU007/733	Screw
254/CA011/925	Top Panel Model DR20
254/CA011/987	Top Panel Model DR30
254/CA012/073	Panel Model DR50
254/CA013/027	Panel Model DR75
254/CA011/546	Cover Plate Models DR50 and DR75
254/CSA01/435	Coin Box
254/EA000/650	Microswitch
254/CA013/047	Air Channel Drum Model DR20
254/CA011/991	Air Channel Drum Model DR30
254/CA013/083	Air Channel Drum Model DR50; Steam
254/CA013/026	Air Channel Drum Model DR75; Gas and electric
254/CA013/095	Air Channel Drum Model DR75; Steam
254/CA012/070	Air Channel Drum Model DR50; Gas and electric
254/CB000/036	Bolt
254/TU002/846	Washer
254/TU002/847	Washer
254/CSA00/839	Lint Filter Models DR20, DR30 and DR50
254/CSA00/817	Lint Filter Model DR75
254/CSA01/528	Dust Filter Models DR20, DR30 and DR50
254/CSA01/545	Dust Filter Model DR75
254/TU003/211	Leveling Leg
254/CA011/956	Dust Filter Model DR30
254/CA011/931	Dust Filter Model DR20
254/CA011/955	Lower Drum Model DR30
254/CA011/934	Lower Drum Model DR20
254/CA011/933	Top Drum Model DR30
254/CA011/932	Top Drum Model DR20
254/CA011/764	Burner Model DR30

254/CA011/763	Burner Model DR20
254/CSA01/425	Complete Side Insulation Model DR50
254/CSA01/512	Complete Side Insulation Model DR75
254/CA013/067	Plate Assembly
254/TU003/400	Nut
254/00007/00	Temperature and Humidity Sensor 1700 mm
254/00008/00	Temperature and Humidity Sensor 2000 mm
254/00009/00	Temperature and Humidity Sensor 2300 mm
254/TU003/266	Nut
254/EA000/594	Temperature Switch
254/M0000/262	Screw
254/SB000/952	Screw
254/TU007/733	Screw
254/TU003/400	Nut
254/00058/00	Temperature and Humidity Sensor 1700 mm
254/00059/00	Temperature and Humidity Sensor 2000 mm
254/00071/10	Temperature and Humidity Sensor 2300 mm
254/TU003/266	Nut
254/EA000/594	Temperature Switch
254/00062/00	Plate Assembly
207/0004/00	Screw
204/0007/00	Nut
203/00006/00	Washer
254/00063/00	Thermostat/Hygrometer Protection
254/SB000/952	Screw
254/TU007/733	Screw
254/00061/00	Top Plate Assembly
254/CSA01/408	Front Panel Model DR30
254/CSA01/416	Front Panel Model DR20
254/CSA01/423	Complete Front Panel Model DR50
254/CSA01/424	Front Panel Model DR50
254/CSA01/510	Complete Front Panel Model DR75
254/CSA01/511	Front Panel Model DR75
254/CA000/856	Fender Panel Models DR20 and DR30
254/CA000/857	Fender Panel Model DR50
254/CA000/858	Fender Panel Model DR75
254/LA000/121	Lock Models DR50 and DR75
254/LA000/119	Key Models DR50 and DR75
254/LA000/121	Lock Models DR20 and DR30
254/LA011/941	Lock
254/CA013/098	Draught Band Models DR50 and DR75
254/TU002/853	Draught Band Models DR20 and DR30
254/CA010/085	Axle
254/CA000/617	Cap
254/SB000/936	Screw Models DR20 and DR30

254/SB000/951	Screw Models DR50 and DR75
254/SB000/971	Key
254/00048/00	Plate Assembly
254/TU007/733	Screw
254/SB000/924	Screw
254/SB000/938	Washer
254/CA000/699	Coin Box
254/00017/00	Magnetic Switch Holder
254/SB000/975	Screw
254/ESA00/862	Reed Switch Assembly
254/CSA01/380	Panel Model DR20; OPL
254/CSA01/392	Panel Model DR30; OPL
254/CSA01/406	Panel Model DR30; Coin
254/CSA01/414	Panel Model DR20; Coin
254/CSA01/427	Panel Model DR50; Coin
254/CSA01/433	Panel Model DR50; OPL
254/CSA01/514	Panel Model DR75; OPL
254/CSA01/524	Panel Model DR75; Coin
254/TU007/733	Screw
254/TU003/213	Rivet
254/TU002/876	Lock
254/CA000/675	Insulation Panel Model DR20
254/CA000/676	Insulation Panel Model DR30
254/CSA01/426	Insulation Panel Model DR50; Coin
254/CSA01/432	Insulation Panel Model DR50; OPL
254/CSA01/513	Insulation Panel Model DR75; OPL
254/CSA01/523	Insulation Panel Model DR75; Coin
209/00099/06	Contact Switch
209/00099/05	Contact
209/00520/00	Telem Sticker
209/00248/00	Mushroom Pushbutton
254/00010/00	Door
254/SB000/967	Screw
254/MD000/359	Door Gasket
254/00011/00	Door Glass
254/00049/00	Screw Set of 3
254/00010/01	Door Glass Holder
254/MD000/337	Reed Switch Magnet
254/SB000/982	Bolt
254/00013/00	Door Hinge
254/SB000/852	Washer
254/P0000/219	Screw
258/TU150/730	Door Hinge
254/MD000/377	Reed Switch Magnet
254/SB000/852	Washer

258/SB009/210	Screw
258/TU151/070	Door Glass
258/TU151/080	Gasket
258/TU150/760	Door
258/TU484/000	Nut
258/CA123/180	Screw
258/MD003/600	Gasket
254/SB000/949	Screw
254/CA000/828	Door Fender Model DR20
254/CA000/833	Door Fender Model DR30
254/CA000/838	Door Fender Model DR50
254/CA000/839	Door Fender Model DR75
254/CSA01/097	Front Panel Model DR20; Coin
254/CSA01/098	Front Panel Model DR30; Coin
254/CSA01/099	Front Panel Model DR50; OPL
254/CSA01/383	Front Panel Model DR20; OPL
254/CSA01/387	Front Panel Model DR30; OPL
254/CSA01/429	Front Panel Model DR50; Coin
254/CSA01/516	Front Panel Model DR75; OPL
254/CSA01/593	Front Panel Model DR75; Coin
254/CA011/929	Insulation Panel Model DR20
254/CA011/930	Insulation Panel Model DR30
254/CA012/029	Insulation Panel Model DR50
254/CA013/131	Insulation Panel Model DR75
254/TU007/733	Screw
254/TU002/853	Draught Band
254/CA000/645	Door Trim Model DR20
254/CA000/646	Door Trim Model DR30
254/CA000/647	Door Trim Model DR50
254/CA000/697	Door Trim Model DR75
254/00019/00	Clean Lint Screen Label
254/CA000/655	Fender
254/LA000/121	Lock Models DR50 and DR75
254/LA000/119	Key Models DR50 and DR75
254/LA000/121	Lock Models DR20 and DR30
254/LA011/359	Lock Hatch
254/LA000/123	Lock Hatch Assembly Models DR50 and DR75
254/LA000/124	Lock Hatch Assembly Models DR20 and DR30
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
254/00015/00	Keypad Label

254/00021/00	Operating Touchpad
254/CSA01/529	Operating Door
209/00506/00	Fuse
254/00043/00	Timer
254/00024/00	Control Board Reversing
254/00030/00	Control Board Non-reversing
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
254/00069/00	Keypad Label
254/00021/00	Operating Touchpad
254/CSA01/529	Operating Door
209/00506/00	Fuse
254/00066/00	Control Board
254/00067/00	Control Board
254/TU014/701	Spacer
254/TUD00/367	Nut
254/00033/00	Keypad Label
254/TU007/733	Screw
254/CSA01/530	Operating Door
209/00506/00	Fuse
254/00043/00	Timer
254/00024/00	Control Board
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
204/00008/00	Nut
203/00007/00	Washer
207/00108/00	Screw
209/00305/00	Coin Meter
254/LA000/401	Lock
254/CA011/265	Front Plate
254/CSA00/753	Coin Box
254/TU009/225	Coin Vault
254/00033/00	Keypad Label
254/TU007/733	Screw
254/CSA01/530	Operating Door
254/TU014/701	Spacer
254/TUD00/367	Nut

209/00506/00	Fuse
254/00067/00	Control Board
254/00066/00	Control Board
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
204/00008/00	Nut
203/00007/00	Washer
207/00108/00	Screw
209/00305/00	Coin Meter
254/LA000/401	Lock
254/CA011/265	Front Plate
254/CSA00/753	Coin Box
254/TU009/225	Coin Vault
254/00039/00	Operating Touchpad
254/CSA01/535	Operating Door
254/TU007/733	Screw
209/00266/01	Eprom
209/00507/00	Fuse
254/00070/00	Control Board
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
254/00018/00	Control Label
254/CSA01/535	Operating Door
254/TU007/733	Screw
209/00266/01	Eprom
209/00507/00	Fuse
254/00070/00	Control Board
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
254/00018/00	Control Label
254/CSA01/535	Operating Door
254/TU007/733	Screw
209/00266/01	Eprom

209/00507/00	Fuse
254/TU014/01	Spacer
254/TUD00/367	Nut
254/00070/00	Control Board
254/SB000/868	Duct
254/EA000/395	Wiring Clip
254/SB000/898	Bolt
254/TU011/613	Washer
254/TU002/842	Nut
254/SB000/836	Screw
254/TU014/414	Rotation Sensor
254/00039/00	Operating Touchpad
254/CSA00/845	Drum
254/CSA00/823	Trunnion
254/TU005/439	Bolt
254/TU002/814	Washer
254/SB000/843	Washer
254/C0000/249	Nut
254/VSB00/130	Washer
254/CA010/355	Reinforcement Bracket
254/DA000/418	Bar Drum
254/SB000/835	Screw
254/CSA00/847	Drum
254/CSA01/434	Trunnion
254/TU005/439	Bolt
254/TU002/814	Washer
254/SB000/843	Washer
254/C0000/249	Nut
254/VSB00/130	Washer
254/00050/00	Reinforcement Bracket
254/DA000/445	Bolt
254/SB000/835	Screw
254/CSA01/540	Drum Model DR50; RVS
254/CSA00/848	Drum Model DR50; Galvanized
254/CSA01/591	Drum Model DR75; RVS
254/CSA00/849	Drum Model DR75; Galvanized
254/CSA00/822	Trunnion Assembly Model DR50
254/CSA00/729	Trunnion Assembly Model DR75
254/TU005/439	Bolt
254/TU002/814	Washer
254/SB000/843	Washer
254/TU004/787	Nut
254/C0000/249	Nut Model DR50
254/TU002/814	Washer Model DR75
154/00002/06	Shim

254/00050/00	Reinforcement Bracket
254/DA011/249	Bolt Model DR50
254/DA011/248	Bolt Model DR75
254/SB000/835	Screw
254/CA012/073	Panel Model DR50
254/CA013/027	Panel Model DR75
254/CSA50/035	Side Panel Model DR20
254/CSA50/036	Side Panel Model DR30
254/CA011/937	Back Panel Model DR20
254/CA011/975	Back Panel Model DR30
254/CA012/016	Back Panel Model DR50
254/CA013/018	Back Panel Model DR75
254/CA011/936	Cover Plate
254/TU007/733	Screw
254/EA000/466	Terminal Models DR50 and DR75
254/CSA01/284	Valve
254/CSA00/971	Vent Pipe Models DR20 and DR30
254/EA000/211	Tube Connector
254/EA000/234	Tubing
254/EA000/212	Tube Connector
254/CA011/854	Bracket
254/SB000/955	Screw
254/TU007/733	Screw
254/CA011/853	Air Valve
254/SB000/954	Switch Assembly Plate
254/EA000/618	Airflow Switch
254/DA000/519	Belt Pulley
254/TU005/881	Key For drum axle
254/DA000/420	Ball Bearing
254/DSA00/690	Bearing
254/SB000/876	Wiring Rod
254/C0000/249	Nut
254/TU004/787	Nut
254/VSB00/134	Washer
254/IB000/140	Washer
254/IB000/139	Bolt
254/SB000/935	Bolt
254/FB000/124	Bolt
254/VSB00/130	Washer
254/TU002/814	Washer
254/DA000/519	Belt Pulley
254/TU005/881	Key
254/DSA00/728	Bearing
254/SB000/876	Wiring Rod
254/C0000/249	Nut

254/TU004/787	Nut
254/VSB00/134	Washer
254/IB000/140	Washer
254/IB000/139	Bolt
254/SB000/935	Bolt
254/DA000/421	Ball Bearing
254/DA011/899	Belt Pulley
254/DA011/914	Key
254/DA000/421	Ball Bearing
254/DSA00/728	Bearing Model DR50
254/DSA00/719	Bearing Model DR75
254/SB000/876	Wiring Rod
254/C0000/249	Nut
254/TU004/787	Nut
254/VSB00/134	Washer
254/IB000/140	Washer
254/IB000/139	Bolt
254/SB000/935	Bolt
254/DA000/421	Ball Bearing Model DR50
254/DA000/423	Ball Bearing Model DR75
254/DA000/530	Pulley
254/DA000/531	Pulley
254/DA011/711	Idler Shaft
254/TUD00/187	Key
254/FB000/124	Bolt
254/VSB00/130	Washer
254/CA011/866	Mounting Bracket
254/DA000/518	Bearing
254/DA000/517	Pulley Housing
254/TU002/814	Washer
254/C0000/249	Nut
254/DSA00/734	Bolt Set of 2 with axis
254/IB000/140	Washer
254/VSB00/134	Washer
254/TU004/787	Nut
254/DA000/521	Belt
254/DA000/523	Belt Model DR30
254/DA000/522	Belt Model DR20
254/DA000/529	Pulley Models DR50 and DR75
254/DA000/531	Pulley Models DR20 and DR30
254/DA000/523	Belt Models DR30 and DR50; Reversing
254/DA000/522	Belt Model DR20
254/DA000/497	Belt Models DR50 and DR75; Reversing and non-reversing
254/DA000/494	Belt Model DR50; Non-reversing
254/DA000/525	Belt Model DR75; Non-reversing

254/DA011/908	Belt Model DR75; Reversing
254/FB000/124	Bolt
254/VSB00/130	Washer
254/CA012/059	Plate Assembly
254/DA000/518	Bearing
254/DA000/517	Pulley Housing
254/TU002/814	Washer
254/C0000/249	Nut
254/SB000/935	Bolt
254/DA011/711	Idler Shaft
254/TUD00/187	Key
254/DA000/528	Pulley Models DR50 and DR75
254/DA000/530	Pulley Models DR20 and DR30
254/DA000/521	Belt
254/DA000/424	Motor Assembly 240-415 Volt
254/DA000/428	Motor Assembly 115-220 Volt
254/TU002/814	Washer
254/FB000/124	Bolt
254/DSA00/703	Motor Plate Assembly Model DR20
254/DSA00/704	Motor Plate Assembly Model DR30
254/SB000/842	Clipnut
254/IB000/140	Washer
254/VSB00/134	Washer
254/TU004/787	Nut
254/TU003/246	Bolt
254/SB000/836	Screw
254/DSA00/773	Fan Model DR30
254/DSA00/772	Fan Model DR20
254/SB000/813	Nut
254/SB000/847	Washer
254/EA000/211	Tube Connector
254/EA000/648	Tube Connector
254/DA000/508	Pulley Model DR30; 50 Hertz
254/DA000/510	Pulley Model DR20; 50 Hertz
254/DA000/516	Pulley Model DR20; 60 Hertz
254/DA000/509	Pulley Model DR30; 60 Hertz
254/DA000/424	Motor Assembly 240-415 Volt
254/DA000/428	Motor Assembly 115-220 Volt
254/DA011/907	Motor Assembly Models DR50 and DR75; 240 Volt
254/TU002/814	Washer Models DR20 and DR30
254/TU005/439	Bolt Models DR50 and DR75
254/FB000/124	Bolt Models DR20 and DR30
254/TU002/814	Washer Models DR50 and DR75
254/DSA00/799	Motor Plate Assembly Model DR20
254/DSA00/801	Motor Plate Assembly Model DR30

254/DSA00/793	Motor Plate Assembly Models DR50 and DR75
254/SB000/842	Clipnut
254/SB000/836	Screw
254/DSA00/773	Fan Models DR30, DR50 and DR75
254/DSA00/772	Fan Model DR20
254/SB000/813	Nut
254/SB000/847	Washer
254/IB000/140	Washer
254/VSB00/134	Washer
254/TU004/787	Nut
254/DA000/460	Dust Cover
254/EA000/648	Tube Connector
254/EA000/211	Tube Connector
254/DA011/919	Pulley Model DR20; 50 Hertz
254/TU014/689	Pulley Model DR30; 50 Hertz
254/DA000/516	Pulley Model DR20; 60 Hertz
254/DA000/509	Pulley Model DR30; 60 Hertz
254/00036/00	Telem Models DR20 and DR30
209/00284/00	Protector Models DR20 and DR30
254/DA011/907	Motor Assembly
254/TU002/814	Washer
254/FB000/124	Bolt Models DR20 and DR30
254/TU005/439	Bolt Models DR50 and DR75
254/DSA00/799	Motor Plate Assembly Models DR20 and DR30
254/DSA00/793	Motor Plate Assembly Models DR50 and DR75
254/SB000/842	Clipnut
254/SB000/836	Screw
254/DSA00/772	Fan Model DR20
254/DSA00/773	Fan Models DR30, DR50 and DR75
254/SB000/813	Nut
254/SB000/847	Washer
254/IB000/140	Washer
254/VSB00/134	Washer
254/TU004/787	Nut
254/DA000/460	Dust Cover Models DR50 and DR75
254/EA000/648	Tube Connector
254/EA000/211	Tube Connector
254/DA011/909	Motor
254/EA000/648	Tube Connector
254/EA000/211	Tube Connector
254/DA000/512	Pulley 2.50-5/8 inch
254/TU014/690	Pulley Models DR20 and DR30; 2.20-5/8 inch
254/DA011/913	Pulley Models DR20 and DR30; 2.00-5/8 inch
254/DA000/513	Pulley Models DR50 and DR75; 60 Hertz; 3.00-5/8 inch
254/DA011/906	Pulley Models DR50 and DR75; 50 Hertz; 2.80-5/8 inch

254/00044/00	Mounting Plate Model DR20
254/00045/00	Mounting Plate Model DR30
254/SB000/842	Clipnut Models DR20 and DR30
254/IB000/140	Washer Models DR20 and DR30
254/VSB00/134	Washer Models DR20 and DR30
254/TU003/246	Bolt Models DR20 and DR30
254/TU002/814	Washer
254/FB000/124	Bolt
254/CA011/935	Mounting Plate
254/SB000/868	Duct
209/00438/00	Central Control Board 240 Volt
209/00471/00	Central Control Board 24 Volt
211/00120/00	Standoff
203/00006/00	Washer
204/00007/00	Nut
254/SB000/867	Duct
254/TU002/793	Screw
254/GA011/007	Ignition Module
254/GA000/803	Cable
254/EA000/651	Relay
211/00117/00	Cordlock
720/00094/02	Cordlock
254/TU007/733	Screw
254/EA000/647	Relay
254/EA000/467	Terminal Block
254/EA000/466	Terminal
254/SB000/836	Screw
254/ESA00/843	Jumper
254/ESA00/857	Transformer
720/00110/01	Rail
254/EA000/685	Contactactor
254/00036/00	Telem
209/00284/00	Protector
254/CA011/935	Mounting Plate
254/EA000/466	Terminal
254/TU007/733	Screw
254/ESA00/843	Jumper
254/ESA00/857	Transformer
209/00438/00	Central Control Board
211/00120/00	Standoff
203/00006/00	Washer
204/00007/00	Nut
254/SB000/868	Duct
254/SB000/867	Duct
254/00022/00	Contactactor

254/00023/00	Contactactor
209/00319/00	Clamp
254/EA000/682	Fuse Holder
254/EA000/683	Fuse
211/00097/00	Cordlock
720/00094/02	Cordlock
209/00356/00	Noise Suppressor
254/EA000/647	Relay
254/EA000/551	Clamp
254/EA000/550	Rail
254/EA000/460	Fuse Holder
254/EA000/457	Fuse
254/SB000/836	Screw
720/00110/01	Rail
254/EA000/685	Contactactor
254/00036/00	Telem
209/00284/00	Protector
254/GSA00/250	Burner Housing Model DR20
254/GSA00/255	Burner Housing Model DR30
254/TU011/613	Washer
254/SB000/831	Bolt
254/GA000/739	Burner Model DR20
254/GA000/756	Burner Model DR30
254/OP000/290	Gas Valve Model DR20
254/LB000/020	Gas Valve Model DR30
254/GA000/770	Gas Valve
254/00038/00	Connector
254/TU002/793	Screw
254/CA011/818	Gas Pipe
254/TU013/217	Gas Pipe Model DR20
254/FG000/274	Gas Pipe Model DR30
254/FB000/124	Bolt
254/TU002/814	Washer
254/39050/105	Elbow
254/OP000/308	Gas Pipe
254/GA000/746	Gas Pipe
254/GA000/760	Connection Pipe
254/CA010/541	Inspection Hole
254/SB000/853	Washer
254/EA000/245	Safety Thermostat
254/TU007/733	Screw
254/CA011/028	Thermostat
254/GA761/147	Gas Orifice Model DR20; No. 26
254/GA761/129	Gas Orifice Model DR30; No. 30
254/GA761/120	Gas Orifice Model DR30; No. 31

254/GA761/086	Gas Orifice Model DR20; No. 44
254/GA761/081	Gas Orifice Model DR30; No. 46
254/TU003/266	Nut
254/AT000/368	Washer
254/M0000/262	Screw
254/GA011/002	Gas Ignition
254/GA010/457	Bracket
254/GSA00/507	Bracket
254/GSA00/255	Burner Housing Model DR50
254/GSA00/767	Burner Housing Model DR75
254/TU011/613	Washer
254/SB000/831	Bolt
254/GSA00/756	Burner
254/OP000/308	Gas Pipe Model DR50
254/TU004/601	Gas Pipe Model DR75
254/CA013/099	Gas Reducer
254/GA000/770	Gas Valve
254/00038/00	Connector
254/TU007/733	Screw
254/CA011/818	Gas Pipe
254/TU007/358	Gas Pipe
254/TU005/439	Bolt
254/VSB00/130	Washer
254/39050/105	Elbow
254/OP000/296	Gas Pipe Model DR75
254/OP000/308	Gas Pipe Model DR50
254/GA000/746	Gas Pipe
254/GSA00/508	Connection Pipe Model DR50
254/GSA00/509	Connection Pipe Model DR75
254/CA010/541	Inspection Hole
254/TU002/793	Screw
254/SB000/853	Washer
254/EA000/245	Safety Thermostat
254/CA011/028	Thermostat
254/GA761/140	Gas Orifice 3.5; No. 9/16
254/GA761/078	Gas Orifice 2; No. 5/64
254/GA761/157	Gas Orifice Model DR50; 4; No. 22
254/GA761/089	Gas Orifice Model DR50; 2.3; No. 43
254/TU003/266	Nut
254/AT000/368	Washer
254/M0000/262	Screw
257/GA011/003	Electrode
254/GA010/457	Bracket
254/ESA00/316	Adapter Models DR20 and DR30
254/CA011/984	Cap

254/TU007/733	Screw
254/SB000/868	Duct
254/EA010/714	Plate Assembly Models DR20 and DR30
254/EA011/613	Plate Assembly Models DR50 and DR75
254/VSB00/130	Washer
254/SB000/935	Bolt Models DR20 and DR30
254/TU005/439	Bolt Models DR50 and DR75
254/ESA00/610	Heating Cover
254/EA000/595	Cap Models DR20 and DR30
254/EA010/232	Cap Models DR50 and DR75
254/EA000/243	Safety Thermostat
254/EA000/472	Heating Element
254/EA010/417	Jumper
254/TU011/613	Washer
254/TU002/842	Nut
254/00027/00	Steam Battery Model DR20
254/00028/00	Steam Battery Model DR30
254/00029/00	Steam Battery Models DR50 and DR75
254/00037/00	Support Bracket Model DR20
254/00046/00	Support Bracket Model DR30
254/00047/00	Support Bracket Models DR50 and DR75
254/TU007/733	Screw
209/00185/00	Steam Valve
905P3	Security Kit Hood lock
203328	Network Retrofit Kit Wired
204689	Wireless Network Kit
203346	USB IR Interface Kit
NK220	Network Controller Kit Wired
NK320	Ethernet Gateway Kit Wireless
NK330	USB Gateway Kit Wireless
905P3	Security Kit Hood lock
204689	Wireless Network Kit
203328	Network Retrofit Kit Wired
203346	USB IR Interface Kit
NK220	Network Controller Kit Wired
NK320	Ethernet Gateway Kit Wireless
NK330	USB Gateway Kit Wireless
38462P	Coin Drop Assembly Token; 118-1 mzp; .880 diameter x .079 thick; Brass
38463	Coin Drop Assembly Token; 118-5 mzp; .990 diameter x .081 thick; Silver
38464P	Coin Drop Assembly Canada; .25
38475	Coin Drop Assembly Japan; 100 yen
CK077	Coin Drop Kit Taiwan; 10 NT
70441601P	Coin Drop U.S.; \$.25
38963P	Coin Drop Token 118-16 not available; Replacement for 38963P Coin
CK114	Coin Drop Assembly Singapore; Old 1.00

CK123	Coin Drop Kit Singapore; New 1.00
29786	Nut
200674P	Opto Coupler
201595P	Wire Guard Anti-stringing security device; Add to coin drops beginning
70441602	Coin Drop Assembly Canada; .25 and 1.00
38467	Coin Drop Assembly Australia; .20 and 1.00
38472	Coin Drop Assembly England; 20 pence and 1 pound
38519	Coin Drop Assembly Japan; 100 and 500 yen
38521	Coin Drop Assembly Korea; 100 and 500 won
70482401	Coin Drop Assembly New Zealand; 1.00 and 2.00
39157	Coin Drop Assembly Israel; 1 and 5 shekel
38725	Coin Identification Paper For use with items 2 and 3
CK115	Electronic Coin Drop Kit Includes items 3-5; United States and Canada coins
CK099	Electronic Coin Drop Kit Includes items 3-5; Australia, New Zealand, Hong Ki
CK100	Electronic Coin Drop Kit Includes items 3-5; Euro and Great Britain coins
CK101	Electronic Coin Drop Kit Includes items 3-5; Euro, Denmark and Norway coin
CK103	Electronic Coin Drop Kit Includes items 3-5; Euro, Lithuania and Latvia coins
CK106	Electronic Coin Drop Kit Includes items 3-5; Malaysia, Russia, China and
CK108	Electronic Coin Drop Kit Includes items 3-5; South Africa coins
CK109	Electronic Coin Drop Kit Includes items 3-5; Euro coins
CK110	Electronic Coin Drop Kit Includes items 3-5; Mexico, Ecuador and United Sta
CK113	Electronic Coin Drop Kit Includes items 3-5; Japan and Taiwan coins
CK116	Electronic Coin Drop Kit Includes items 3-5; Malaysia and China coins
CK117	Electronic Coin Drop Kit Includes items 3-5; Russia coins
CK118	Electronic Coin Drop Kit Includes items 3-5; Philippine coins
CK120	Electronic Coin Drop Kit Includes items 3-5; Chile coins
CK121	Electronic Coin Drop Kit Includes items 3-5; Singapore coins
70294103P	Electronic Coin Drop Assembly Euro and Great Britain coins
70294104	Electronic Coin Drop Assembly Euro, Denmark and Norway coins
70513306	Electronic Coin Drop Assembly Mexico, Ecuador and United States coins
70294107	Electronic Coin Drop Assembly Euro, Lithuania and Latvia coins
70294109	Electronic Coin Drop Assembly Malaysia, Russia, China and Singapore coins
70294110	Electronic Coin Drop Assembly South Africa coins
70294111	Electronic Coin Drop Assembly Euro coins
70513311	Electronic Coin Drop Assembly Malaysia and China coins
70294117	Electronic Coin Drop Assembly Russia coins
70294120	Electronic Coin Drop Assembly Chile coins
70294121	Electronic Coin Drop Assembly Singapore coins
201216	Nut For use with items 2 and 3
201104	Coin Drop Wire Harness For use with items 2 and 3
CK096	Mounting Tool Kit For use with items 2 and 3
201572	Clip For use with items 2 and 3
203346	USB IR Interface Kit
204689	Wireless Network
203328	Network Retrofit Kit Wired

NK220	Network Controller Wired
NK320	Ethernet Gateway Wireless
NK330	USB Gateway Kit Wireless
203346	USB IR Interface Kit
204689	Wireless Network Kit
203328	Network Retrofit Kit Wired
NK220	Network Controller Kit Wired
NK320	Ethernet Gateway Kit Wireless
NK330	USB Gateway Kit Wireless
D513777B	Control Panel and Bracket Assembly Black; Models HDENXAGS173CN01,
D513777DG	Control Panel and Bracket Assembly Dark gray; Models PD3JXAGS403UG01,
D513777W	Control Panel and Bracket Assembly White; All other models
F8536002	Wireless Network Board Harness Through Serial No. 1902000001
F8674006	Wireless Network Harness Starting Serial No. 1902000001
204689	Wireless Network Kit Through Serial No. 1902000001
807211	Wireless Network Control Assembly Starting Serial No. 1902000001
70441602	Coin Drop Assembly Canada; .25 and 1.00
38467	Coin Drop Assembly Australia; .20 and 1.00
38472	Coin Drop Assembly England; 20 pence and 1 pound
38519	Coin Drop Assembly Japan; 100 and 500 yen
38521	Coin Drop Assembly Korea; 100 and 500 won
70482401	Coin Drop Assembly New Zealand; 1.00 and 2.00
39157	Coin Drop Assembly Israel; 1 and 5 shekel
802905	Harness Assembly Coin drop
29786	Nut
201595P	Wire Guard Anti-stringing security device
38462P	Coin Drop Assembly Token; 118-1 mzp; .880 diameter x .079 thick; Brass
38463	Coin Drop Assembly Token; 118-5 mzp; .990 diameter x .081 thick; Silver
38464P	Coin Drop Assembly Canada; .25
38475	Coin Drop Assembly Japan; 100 yen
CK077	Coin Drop Kit Taiwan; 10 NT
70441601P	Coin Drop U.S.; \$.25
38963P	Coin Drop Token 118-16 not available; Replacement for 38963P
CK114	Coin Drop Assembly Singapore; Old 1.00
CK123	Coin Drop Kit Singapore; New 1.00
38725	Coin Identification Paper For use with items 2 and 3
CK115	Electronic Coin Drop Kit Includes items 3, 4 and 7; United States and Canada
CK099	Electronic Coin Drop Kit Includes items 3, 4 and 7; Australia, New Zealand, U.S.
CK100	Electronic Coin Drop Kit Includes items 3, 4 and 7; Euro and Great Britain coins
CK101	Electronic Coin Drop Kit Includes items 3, 4 and 7; Euro, Denmark and Norway
CK103	Electronic Coin Drop Kit Includes items 3, 4 and 7; Euro, Lithuania and Latvia
CK106	Electronic Coin Drop Kit Includes items 3, 4 and 7; Malaysia, Russia, China and
CK108	Electronic Coin Drop Kit Includes items 3, 4 and 7; South Africa coins
CK109	Electronic Coin Drop Kit Includes items 3, 4 and 7; Euro coins
CK110	Electronic Coin Drop Kit Includes items 3, 4 and 7; Mexico, Ecuador and United States

CK113	Electronic Coin Drop Kit Includes items 3, 4 and 7; Japan and Taiwan coins
CK116	Electronic Coin Drop Kit Includes items 3, 4 and 7; Malaysia and China coins
CK117	Electronic Coin Drop Kit Includes items 3, 4 and 7; Russia coins
CK118	Electronic Coin Drop Kit Includes items 3, 4 and 7; Philippine coins
CK120	Electronic Coin Drop Kit Includes items 3, 4 and 7; Chile coins
CK121	Electronic Coin Drop Kit Includes items 3, 4 and 7; Singapore coins
70294103P	Electronic Coin Drop Assembly Euro and Great Britain coins
70294104	Electronic Coin Drop Assembly Euro, Denmark and Norway coins
70513306	Electronic Coin Drop Assembly Mexico, Ecuador and United States coins
70294107	Electronic Coin Drop Assembly Euro, Lithuania and Latvia coins
70294109	Electronic Coin Drop Assembly Malaysia, Russia, China and Singapore coins
70294110	Electronic Coin Drop Assembly South Africa coins
70294111	Electronic Coin Drop Assembly Euro coins
70294122	Electronic Coin Drop Assembly Euro, Great Britain and token
70513311	Electronic Coin Drop Assembly Malaysia and China coins
70294117	Electronic Coin Drop Assembly Russia coins
70294120	Electronic Coin Drop Assembly Chile coins
70294121	Electronic Coin Drop Assembly Singapore coins
201104	Coin Drop Wire Harness For use with items 2 and 3
CK096	Mounting Tool Kit For use with items 2 and 3
201572	Clip For use with items 2 and 3
29786	Nut
807396B	Meter Case Assembly Black; Requires high capacity coin vault; Models
807254DG	Meter Case Assembly Dark gray; Requires high capacity coin vault; Models
807396W	Meter Case Assembly White; Requires high capacity coin vault; All other mc
804104B	Wrapper Assembly Black; Models HDENXAGS173CN01, HDENXAGW173CN0
804104DG	Wrapper Assembly Dark gray; Models PD3JXAGS403UG01, PDEJXAGS434AG
804103W	Wrapper Assembly White; Models JDEJRAGW303EW01 and JDGJRAGW303
804104W	Wrapper Assembly White; All other models
70240301	Screw 6 required
803998	Rear Access Panel
70030501	Expansion Clip 6 required
44087201	Nut
803970B	Control Panel Models JDEJGAGW303EW01, JDEJGASW303EN01,
803962BP	Control Panel Black; Models HDENXAGS173CN01, HDENXAGW173CN01,
803962DG	Control Panel Dark gray; Models PD3JXAGS403UG01, PDEJXAGS434AG01,
803962WP	Control Panel White; All other models
M405188	Screw Use with stainless steel side panels
36020	Nut
803869	Top Panel Stainless steel; Models HDENXAGS173CN01,
804023DG	Top Panel Dark gray; Models PD3JXAGS403UG01,
803868WP	Top Panel White; All other models
29651	Bolt
36226	Bumper Pad 4 required
36226	Bumper Pad 4 required

804614	Rear Access Panel
56079	Panel Locator
39733	Screw
28835	Speed Clip
27604P	Anti-Seize Compound Apply to motor shaft when installing blower fan asse
D505843P	Motor and Pulley 240 Volt/50 Hertz; Includes items 4-5; Apply anti-seize co
D505869P	Motor and Pulley 240 Volt/60 Hertz; Includes items 4-5; Apply anti-seize co
D516608P	Motor and Pulley 115 Volt/50 Hertz; Includes items 4; Apply anti-seize com
D511629P	Motor and Pulley 120 Volt/60 Hertz; Includes items 4-5; Apply anti-seize co
27604P	Anti-Seize Compound Apply to motor shaft when installing blower fan asse
D510238P	Blower Housing Seal
31260	Screw
D510266P	Front Bulkhead Assembly Unpainted; Includes D510207P Cylinder Seal Asse
D510207P	Cylinder Seal Assembly Apply adhesive when installing
D511637P	Adhesive Apply to cylinder seal
RB170001	Seal Kit Includes 2 cylinder seals, D510238P Blower Housing
D510102LG	Cylinder Baffle Light gray; Models BD3NGBSS403UN01,
D510102W	Cylinder Baffle White; All other models
D505929LGP	Cylinder Assembly Stainless steel; Includes item 2; Models
D510265LGP	Cylinder Assembly Galvanized; Includes item 2; Models
D510265WP	Cylinder Assembly Galvanized; Includes item 2; All other models
62588	Screw
D510207P	Cylinder Seal Assembly Apply adhesive when installing
D511637P	Adhesive Apply to cylinder seal
RB170001	Seal Kit Includes 2 cylinder seals, D510238P Blower Housing
M405188	Screw Models BD3NGBSS403UN01, BD3NLBSS403UN01,
20530	Screw
756P3	Conversion Kit 400 Volt, 4 wire WYE to 240 Volt, 3 wire Delta
D510705P	Heater Duct Assembly Includes items 2 and 3
51782	Screw
D510184P	Igniter and Bracket Assembly
23222	Screw
D510149P	Burner Assembly
649P3	L.P. Conversion Kit Used to convert dryers from N.G. or Mixed Gas to L.P. for
599P3	L.P. Conversion Kit Used to convert dryers from N.G. or Mixed Gas to L.P. for
58755	L.P. Orifice 25,000 Btu; 7500-10,999 feet (2290-3354 m)
122P4P	Porcelain Touch-Up White
F140938	Snap Bushing Model JDGJRAGW303EW01
20530	Screw
38384	Strain Relief Models HDGNEAGS113CW01, HDGNERGS113CW01,
D514379P	Junction Box Seal 4 required
00161	Grounding Clip
00189	Female Spade Terminal
00361	Female Piggyback Terminal
58799	2 Circuit Connector

00223	Female Spade Terminal 1/4 inch; (1) 18 gauge wire
00121	Female Spade Terminal 1/4 inch; (2) 18 gauge wires or (1) 12 gauge wire
00245	Spade Terminal 1/4 inch; (1) 22 gauge wire
00124	Female Spade Terminal 3/16 inch; (1) 18 gauge wire; .020 tab
00156	Female Spade Terminal 3/16 inch; Thermostat wire; .032 tab
00222	Female Spade Terminal 1/4 inch
00347	Terminal
00115	Female Spade Terminal 1/4 inch; (1) 18 gauge wire
90789	Receptacle Housing
00359	Insulated Female Spade Terminal 1/4 inch
00165	Insulated Female Terminal 3/16 inch
00110	Ring Terminal (1) 18 gauge wire
00111	Ring Terminal (2) 18 gauge wires or (1) 12 gauge wire
00319	Ring Terminal (2) 18 gauge wires or (1) 14 gauge wire
00114	Female Spade Terminal 1/4 inch; Double connector
00139	Male Tab Terminal 1/4 inch; (2) 18 gauge wires or (1) 12 gauge wire
00344	Female Tab Terminal
00252	Terminal
44370401	1 Circuit Plug Housing
23033	9 Circuit Plug
23041	6 Circuit Plug
26163	9 Circuit Receptacle
56855	12 Circuit Receptacle
00221	Insulated Female Flag Terminal 1/4 inch
26708	6 Circuit Receptacle
26301	1 Circuit Receptacle
54522	Plug
45380	12 Gauge Wire Orange; Order wire by foot; Order terminals and connectors
45001	18 Gauge Wire Black; Order wire by foot; Order terminals and connectors a
45102	18 Gauge Wire Green/Yellow
45380	12 Gauge Wire Orange; Order wire by foot; Order terminals and
45001	18 Gauge Wire Black; Order wire by foot; Order terminals and
45380	12 Gauge Wire Orange; Order wire by foot; Order terminals and
45001	18 Gauge Wire Black; Order wire by foot; Order terminals and
SP530621	Front Panel Assembly U models; I models starting Serial No.11T006637MZ;
SP559831	Front Panel Assembly S models through 12/31/2020; I models and model
SP555996	Front Panel Assembly L, N, P and T models; Includes items 2-12; Gray
SP530620	Front Panel Assembly Includes items 2-12; Stainless steel
SP530623	Front Panel Assembly U models; S models starting 1/1/2021; I models starti
SP559832	Front Panel Assembly S models through 12/31/2020; I models and model
SP555997	Front Panel Assembly L, N, P and T models; Includes items 2-12; Coin; Right
SP530622	Front Panel Assembly Includes items 2-12; Coin; Right door; Stainless steel
SP545543	Front Panel Assembly U models; S models starting 1/1/2021; I models starti
SP559833	Front Panel Assembly S models through 12/31/2020; I models and model
SP555998	Front Panel Assembly L, N, P and T models; Includes items 2-12; Coin; Left c

SP545542	Front Panel Assembly Includes items 2-12; Coin; Left door; Stainless steel
SP309966240410	Bolt
SP515291	Coin Vault Cover Coin
SP311125000004	Washer
SP311127000004	Washer
SP515075	Bolt
SP501514	Coin Vault Frame Coin
SP524394	Coin Vault Frame Bracket Coin
SP309933240412	Bolt
SP514906	Washer
SP514530	Latch
SP524366	Washer
SP530631	Filter Panel Assembly U models; Includes items 2-9; Imitation stainless steel
SP559827	Filter Panel Assembly S models through 12/31/2020; I models and model
SP555961	Filter Panel Assembly L, N, P and T models; Includes items 2-9; Gray
SP530630	Filter Panel Assembly Includes items 2-9; Stainless steel
SP530634	Filter Panel Assembly U models; I models starting Serial No. 11T006637MZ;
SP559828	Filter Panel Assembly S models through 12/31/2020; I models and model
SP555962	Filter Panel Assembly L, N, P and T models; Includes items 2-9; With lock; G
SP530633	Filter Panel Assembly Includes items 2-9; With lock; Stainless steel
SP345900025012	Plug Not applicable for coin
SPPRI610000007	Lock
SPPRI522000012	Washer
SPPRI610001007	Lock Hook
SP521266	Chain
SP521221	Lock
SP520407	Screw
SP520408	Pin Insertion
SP560115	Control Panel Assembly U models; Includes items 1-19; Imitation stainless s
SP559884	Control Panel Assembly U models; Includes items 1-19; Stainless steel
SP560117	Control Panel Assembly I models and models LS250HP_PROFESSIONAL thro
574514	Control Panel Assembly I models; Imitation stainless steel; Starting Serial Nc
SP559885	Control Panel Assembly I, L and N models; Includes items 1-19; Stainless ste
571930	Control Panel Assembly L and N models; Gray; Starting 6/14/19
SP559883	Control Panel Assembly S models through 12/31/2020; Includes items 1-19;
SP559886	Control Panel Assembly S models; Includes items 1-19; Stainless steel
575431	Control Panel Assembly S models starting 1/1/2021; Includes items 1-19; Ir
SP560101	Control Panel Assembly P and T models; Includes items 1-19; Gray; L and N
SP560116	Control Panel Assembly P and T models; Includes items 1-19; Stainless steel
SP560118	Control Panel Assembly P and T models; Includes items 1-19; Black; Throug
SPPRI610000007	Lock
SP528310	Emergency Stop Knob
SP560111	Control Panel U models; Imitation stainless steel; I models starting Serial Nc
SP560113	Control Panel I, LS250HP_PROFESSIONAL and S models; White; Through
SP560106	Control Panel L, N, P and T models; Gray

SP560114	Control Panel P and T models; Black
SP560112	Control Panel Stainless steel
SPPRI522000012	Washer
SPPRI610005007	Nut
SP528311	Emergency Stop
SP528312	Switching Unit
SP529082	Shim
SPPRI610001007	Lock Hook
SPPRI610006007	Nut
SP101275	Gasket
SP556608	Control Board I, L, N, P and T models; Gray
SP102457	Control Board S and U models; Green
SP311679800003	Washer
SP309798500306	Bolt
SP526001	Memory Empty without software version
102471	Memory Models without heat pump; Includes SP526001 Memory and
102472	Memory Models without heat pump; Includes SP526001 Memory and
545269	Memory Models with heat pump; Includes SP526001 Memory and EN,
572334	Memory Models with heat pump; Includes SP526001 Memory and EN,
545270	Memory Models with heat pump; Includes SP526001 Memory and EN,
572335	Memory Models with heat pump and frequency inverter; Includes
SP309933240412	Bolt
SP311125000004	Washer
SP514193	Nut
SP559863	Overlay U models
SP559864	Overlay I, N and S models
SP556100	Overlay L, P and T models
SP560162	Filter Assembly Includes items 20 and 21
SP520404	Door Switch Assembly Includes items 27-34
573370	Coin Vault Assembly Includes items 1, 6, 7, 40 and 41
SP311125000004	Washer
SP517486	Rod
SP309933000416	Bolt
SP273121011001	Bushing
SP514193	Nut
SP311127000004	Washer
SP309933240412	Bolt
SP100388	Switch
SP534602	Upper Cover
SP557135	Upper Cover Single phase
SP530796	Access Cover
SP557136	Access Cover Single phase
SP100218	Screw
SP520891	Switch Panel
SPPRI404000095	Main Switch Knob

SPPRI404000097	Main Switch
SP273121013002	Bushing
SP311125000010	Washer
SP310934000010	Nut
SPPRI504000001	Adjustable Foot
SP506045	Microswitch
SP560160	Fine Filter
SP512324	Filter
SP545533	Exhaust Cover
SP545529	Bolt
SP545531	Washer
SP545530	Nut
SP518505	Front Seal
SP518719	Bolt
SP311127000003	Washer
SP311125000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP516693	Bolt
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP527801	Back Seal Models through Serial No.11T007431UM
579537	Back Seal Models starting Serial No.11T007432UM
SP309933000630	Bolt
SPPRI611000009	Spring
SP534645	Lock Hook
SP310985000006	Nut
SP321848140028	Coin Vault
573350	Coin Vault
573370	Coin Vault Assembly Includes items 18 and 19
SP309933000416	Bolt
SP273121011001	Bushing
SP534602	Upper Cover
SP530796	Access Cover
SP520890	Switch Panel
SPPRI404000095	Main Switch Knob
SP530798	Upper Rear Cover Electric models
569441	Upper Rear Cover Gas models; Also use 569448 Cover
SP100218	Screw
SPPRI404000097	Main Switch Gas and steam models; Electric models 400 or 440V 9kW;
SPPRI404000099	Main Switch Electric models; 208-240V 13.5kW
SP530799	Lower Rear Cover
SP273121013002	Bushing
SP518505	Front Seal
SP527801	Back Seal Models through Serial No.11T007431UM

579537	Back Seal Models starting Serial No.11T007432UM
SP309933000630	Bolt
SP534645	Lock Hook
SP310985000006	Nut
SPPRI611000009	Spring
SP321848140028	Coin Vault
573350	Coin Vault
SP311125000004	Washer
SP311127000004	Washer
SP309933240412	Bolt
SP100388	Switch
SP514193	Nut
SP517486	Rod
SP520404	Door Switch Assembly Includes items 1-9
SP311127000003	Washer
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP518719	Bolt
SP311127000003	Washer
SP311125000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP516693	Bolt
SP310934000010	Nut
SPPRI504000001	Adjustable Foot
SP311125000010	Washer
SP506045	Microswitch
SP512324	Filter
SP545533	Exhaust Cover
SP545529	Bolt
SP545531	Washer
SP545530	Nut
577702	Drum Assembly Galvanized; Includes items 1-7; 3000 RPM
577724	Drum Assembly Stainless Steel; Includes items 1-7; 3000 RPM
SP525028	Bolt
577764	Drum Galvanized
577767	Drum Stainless Steel
SP512233	Washer 1mm
517426	Washer 0.5mm
SP510697	Washer
SP311125000010	Washer
SP310934000010	Nut
573631	Nut
SP514957	Drum Cross 3000 RPM
SP534969	Glue Use with item 5

SP245704003021	Adhesive Use with item 4
SP559703	Door Assembly P and T models; S and U models through Serial No.11T0073
SP556559	Door Assembly I, L and N models; S and U models starting Serial No.11T007
SP524359	Door Assembly L and N models; I models starting Serial No. 11T006637MZ;
SP556561	Door Assembly P and T models through Serial No.11T006636MZ; Heat pum
SP556558	Door Assembly P and T models through Serial No.11T006539MQ; Gas, stea
559702	Door Assembly P and T models starting Serial No.11T006540MQ; S and U rr
SP534873	Door Ring
SP559701	Door P, S, T and U models; Metallic gray
SP524364	Door I, L, N, S and U models; Black
SP556552	Door P and T models; Silver
SP559705	Upper Door Hinge P, S, T and U models; Metallic gray
SP525105	Upper Door Hinge I, L, N, S and U models; Black
SP556555	Upper Door Hinge P and T models; Silver
SP520201	Stop Pin
SP512053	Door Glass
SP310934240004	Nut
SP519933	Outer Door Gasket
SP559706	Lath P, S, T and U models; Metallic gray
SP524582	Lath I, L, N, S and U models; Black
SP556553	Lath P and T models; Silver
SP559704	Lower Door Hinge P, S, T and U models; Metallic gray
SP525104	Lower Door Hinge I, L, N, S and U models; Black
SP556554	Lower Door Hinge P and T models; Silver
SP525101	Bolt
564203	Magnet
SP514530	Latch
SP524367	Bolt
SP534969	Glue Use with item 3
SP245704003021	Adhesive Use with item 7
579505	Door Assembly Gas, steam and electric models; Includes items 1-19; Black
579506	Door Assembly Gas, steam and electric models; Includes items 1-19; Metall
579507	Door Assembly Heat pump models; Includes items 1-19; Black
579508	Door Assembly Heat pump models; Includes items 1-19; Metallic gray
579509	Door Black
579510	Door Metallic gray
SP519933	Outer Door Gasket
SP512053	Door Glass
SP525105	Upper Door Hinge Black
SP559705	Upper Door Hinge Metallic gray
SP525101	Bolt
SP310934240004	Nut
SP520201	Stop Pin
SP524582	Lath Black
SP559706	Lath Metallic gray

SP525104	Lower Door Hinge Black
SP559704	Lower Door Hinge Metallic gray
SP514193	Nut
564203	Magnet Heat pump models
SP514530	Latch
SP524367	Bolt
580337	Plastic Layer Holder
SP515075	Bolt
579513	Handle Black
579514	Handle Metallic gray
SP534873	Door Ring
580339	Fixation Ring Black
579515	Fixation Ring Metallic gray
580338	Door Plastic Layer
SP309798100313	Screw
SP514127	Safety Thermostat
SP516092	Temperature Sensor
SP516669	Washer
SP528941	Heater Box
SP510984	Heating Element 6 kW
SP510985	Heating Element 4.5 kW
SP557786	Fuse
SP527900	Heating Element Bracket
SP309933000616	Bolt
SP311127000006	Washer
SP311125000006	Washer
SP520297	Plug
SP273454410020	Hose
520098	Gas Valve Wiring 60 Hertz; Use with item 18
SP310934240005	Nut
SP512130	Gas Heater Box
SP517238	Screw
SP514127	Safety Thermostat
SP512141	Electrode Bracket
SP100218	Screw
SP311125000003	Washer
SP516060	Ignition Cable
SP309933000516	Bolt
SP311127000005	Washer
SP311125000005	Washer
SP357456010080	Ignition Unit
SP516057	Flame Detection Cable
575643	Ignition Electrode
SP102018	Flange
SP514062	Flange

SP512142	Tube
SP102000	Gas Valve 50 Hertz
SP520281	Gas Valve 60 Hertz
SP512144	Valve Bracket
SPPRI202001001	Bolt
SP512067	Nozzle
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
SP512139	Cover
SP102002	Detection Electrode
SP552515	Burner Tube
SP516092	Temperature Sensor
SP516669	Washer
345000180901	Connector 50 Hertz; Use with item 18
345000160645	Contact 50 Hertz; Use with item 18
SP357500459412	Gas Valve Cable 50 Hertz; Use with item 18
SP102019	Blank Plate Kit Without regulator
571487	Ignition Cable Use with item 22

569440	Gas Heater Box
SP310934000006	Nut M6
SP311127000006	Washer M6
SP311125000006	Washer M6
577644	Stirrup M6 D1/2 inch
569444	Tube 1/2 inch
537625	Cover
572352	Elbow 1/2 inch
572351	Gas Valve
571938	Control Unit
SP309798524408	Bolt M4x8
SP311127000004	Washer M4
SP311125000004	Washer 4.3
569446	Holder
571881	Tube 1/2 inch
572350	Elbow 1/2 inch
571884	Holder
SP100218	Screw ST4.8x13
SP512139	Cover
SP517238	Screw ST 3.6x6.5
SP552515	Burner Tube
575643	Ignition Electrode
571880	Holder
SP516092	Temperature Sensor
SP516669	Washer 2 pcs
572361	Screw ST3.9x13
SP310934240005	Nut M5
SP514127	Safety Thermostat
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310

517253	Orifice 325
575530	Orifice 330
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
SP530409	Steam Exchanger Double row
SP519027	Filter
SP310934240005	Nut
SP311127000005	Washer
SP311125000005	Washer
SP520227	Thermostat Bracket
SP517238	Screw
SP517236	Tube
SP405054057006	Steam Filter 3/4 inch
SP516718	Steam Valve 50 Hertz; With coil
SP514166	Steam Valve Body 60 Hertz; Without coil
SP516717	Coil 60 Hertz
SP514127	Safety Thermostat
SPPRI202001001	Bolt
SP314G00017524	Tube
SPX01140400514	Tube Insert
SP556082	Heat Pump U models; I models starting Serial No. 11T006637MZ; S models
SP556084	Heat Pump U models; I models starting Serial No. 11T006637MZ; S models
SP556090	Heat Pump U models; I models starting Serial No. 11T006637MZ; S models
SP556092	Heat Pump U models; I models starting Serial No. 11T006637MZ; S models
SP556659	Heat Pump I and LS250HP_PROFESSIONAL models through S.N.11T006636F
SP556660	Heat Pump I and LS250HP_PROFESSIONAL models through S.N.11T006636F
SP556663	Heat Pump I and LS250HP_PROFESSIONAL models through S.N.11T006636F
SP556664	Heat Pump I and LS250HP_PROFESSIONAL models through S.N.11T006636F
SP556083	Heat Pump L, N, P and T models; With rinsing system; 380-415V 3AC+N 50Hz
SP556085	Heat Pump L, N, P and T models; With rinsing system; 230V 3AC 50 Hz; Gray
SP556091	Heat Pump L, N, P and T models; Without rinsing system; 380-415V 3AC+N
SP556093	Heat Pump L, N, P and T models; Without rinsing system; 230V 3AC 50 Hz; C
SP541496	Fan Assembly Includes items 1, 2 and 4-6
SP541495	Fan Holder
SP528481	Fan
SP541424	Side Panel U models; I models starting Serial No. 11T006637MZ; S models s

SP556649	Side Panel I and LS250HP_PROFESSIONAL models through S.N.11T006636M
SP556005	Side Panel L, N, P and T models; Left; Gray
SP311125000004	Washer
SP311127000004	Washer
SP309084000416	Bolt
SP101415	Nut
SP541484	Fan Cover
SP101405	Bushing
SP552660	Cabinet
SP537864	Bolt
SP311902100006	Washer
SP506012	Bolt
SP551869	Humidity Sensor
SP541425	Side Panel U models; I models starting S.N. 11T006637MZ; S models startin
SP556650	Side Panel I and LS250HP_PROFESSIONAL through S.N.11T006636MZ; S mo
SP556007	Side Panel L, N, P and T models; Right; Gray
SP101416	Nut
SP101418	Nut
SP101408	Bushing
SP101406	Bushing
SP541494	Swivel Wheel Assembly
SP551864	Swivel Wheel Assembly
SP309933000625	Bolt
SP311679824006	Washer
SP311125000006	Washer
SP310934000006	Nut
SP566259	Cover New style
SP529206	Screw M4x11
SP533726	Bolt
SP310934000020	Nut
SP541489	Base
SP541436	Bracket
SP541457	Thermostat Bracket
SP541435	Cover Through Serial No.11T005334FU
SP566301	Cover Starting Serial No. 11T005335FU
SP551860	Cover
SP541434	Cover
SP556043	Box Assembly Includes items 1-17
SP556044	Box
SP552251	Filter
571478	Frequency Inverter
SP309084000420	Bolt
SP311127000004	Washer
SP311125000004	Washer
SP309933100625	Bolt

SP311125100006	Washer
SP310934100006	Nut
SP311679824006	Washer
SP309084000412	Bolt
SP311679800004	Washer
SP101408	Bushing
SP101416	Nut
SP101406	Bushing
SP101418	Nut
SP502214	Clip
SP556920	Nozzle Holder Assembly Includes items 6, 7, 8 and 9
581723	Time Relay For models with HP Booster
SP556947	Valve Cover Assembly
SP556959	Valve 4-way
SPPRI540000014	Hose
SP101745	Hose Pipe For water approval
SPPRI240000002	Hose Clamp
SP527236	Elbow
SP556916	Nozzle Adapter
SP556915	Nozzle Fitting Adapter
SP556919	Nozzle Bracket Assembly
SP556922	Nozzle
SP556954	Rinsing System Bracket
SP309933000616	Bolt
SP311125000006	Washer
SP311127000006	Washer
SP552666	Insulation
SP556943	Elbow Bracket Assembly
SP101416	Nut
SP101406	Bushing
SP556946	Valve Bracket Assembly
SP506012	Bolt
SP311127000004	Washer
SP311125000004	Washer
SP309084000412	Bolt
SPPRI505000054	Filling Hose Pipe
SP101621	Filling Hose Pipe For water approval
SP534910	Exhaust Assembly Includes items 1-13
SP529013	Clamp
SP144151508341	Tube
SP534914	Tube
SP273127001798	Plug
SP530689	Exhaust Bracket
SP516669	Washer
SP100218	Screw

SP534908	Bar
SP534902	Flap Assembly
SP309933000516	Bolt
SP534900	Flap Stop
SP534929	Nut
SP534904	Plug
SP528928	Tension Assembly Includes items 4, 7, 11, 14, 20 and 23-33
SP310985000006	Nut
SP311125000006	Washer
SP309933000616	Bolt
SP311125000010	Washer
SP505449	Key
SP512365	Reinforcement Bracket
SP310985000010	Nut
SP514005	Bearing
SP514012	Flange Bearing Body
SP514007	Bearing
SP309933001025	Bolt
SP518646	Double Drum Pulley
SP311902100012	Washer
SP311127000010	Washer
SP518647	Belt
SP515257	Belt
SP518649	Distance Ring
SP512366	Bearing Bracket
SP514011	Flange Bearing Body
SP310934000010	Nut
SP514483	Bearing Flange
SP311902100006	Washer
SP515517	Retaining Ring
SP326000600300	Bearing
SP534703	Double Pulley
SP534704	Tension Rod
SP309933001120	Bolt
SP311125000013	Washer
SP310985000012	Nut
SP515514	Support Plate
SP514479	Tension Assembly
SP514480	Sliding Board
SP311902100010	Washer
N/A	Motor Pulley 50 Hertz; Reversing; Refer to item 36
N/A	Motor Pulley 60 Hertz; Reversing; Refer to item 36
SP527723	Motor Pulley 50 Hertz; Nonreversing
SP528922	Motor Pulley 60 Hertz; Nonreversing
SP515418	Motor Bracket 3 Phase; Reversing

SP518517	Motor Bracket 1 Phase; Reversing
579831	Motor and Pulley 3 Phase; 50 Hertz; Reversing
579832	Motor and Pulley 3 Phase; 60 Hertz; Reversing
579834	Motor and Pulley 1 Phase; 50 Hertz; Reversing
579835	Motor and Pulley 1 Phase; 60 Hertz; Reversing
SP518556	Bolt
SP515521	Spacer
SP512363	Drive Bracket
SP309933001050	Bolt
SP523622	Fan Motor 3 phase; Nonreversing
SP523625	Fan Motor 1 phase; Nonreversing
SP520940	Spacer
SP100218	Screw
575503	Fan Housing Weldment
SP520950	Inlet Nozzle
SP309933000625	Bolt
SP311902100006	Washer
SP311902100008	Washer
SP520945	Ventilator
SP101405	Bushing
SP510954	Bolt
SP514016	Safety Thermostat
SP309798500306	Screw
SPPRI505000064	Plug
SP534930	Temperature Sensor
SP101415	Nut
SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 Phase
530518	Electric Box Cover
SP552201	Autotransformer
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP358251506220	Fuse
SP358251601312	Fuse Isolator
569857	Contactactor 208-240V 1AC
569856	Contactactor 208-240V 3AC; 380-415V 3AC
SP552311	Control Relay
SP506586	Relay Case Including Relay Clamp
SP346000209101	End Stop
SP514021	Transformer 208-440 Volt
SP311125000004	Washer
SP309084000410	Bolt
552482	Fuse Housing
SP345805005020	Fuse 250 Volt; T500mA
SPPRI401001021	Fuse 250 Volt; F4A
552483	End Cover
SP346000014010	Cover

SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP346000004010	Fuse Case
SP514057	Relay
569856	Contactator
SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 Phase
569856	Contactator
SP346000209101	End Stop
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
530518	Electric Box Cover
SP358251506220	Fuse 6A
SP358251601312	Fuse Isolator
569856	Contactator 400V 9kW; 400V 13.5kW; 440V 13kW
569857	Contactator 230V 13.5kW need to use with 569856
SP514021	Transformer 208-440 Volt
SP311125000004	Washer
SP309084000410	Bolt
552483	End Cover
552482	Fuse Housing
SP345805005020	Fuse 250 Volt; T500mA
SPPRI401001021	Fuse 250 Volt; F4A
SP346000014010	Cover
SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP346000004010	Fuse Case
SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 Phase
530518	Electric Box Cover
SP514134	Relay Gas models; 220VAC
SP346000280402	Interconnection
SP346000209101	End Stop
569856	Contactator
SP520195	Resistance Bleeder Reversing
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP346000280101	Clamp
SP346000280301	Cover
SP514057	Relay Gas models; 24VAC
SP506586	Relay Case Gas models; Including Relay Clamp
SP514021	Transformer 14.2V plus 24V; 208-440 Volt
SP516648	Transformer 380-415 Volt without N
SP311125000004	Washer
SP309084000410	Bolt
552483	End Cover
552482	Fuse Housing
SPPRI401001021	Fuse 250 Volt F4A
SP345805005020	Fuse 250 Volt T500mA
SPPRI401020021	Fuse 1.6A
SP346000014010	Cover

SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP345805163032	Fuse 1A
SP346000004010	Fuse Case
SP557962	Frequency Inverter
SP520870	Underpressure Clutch Assembly Includes items 1-12
SP516623	Bolt
SP311125000003	Washer
SP518623	Bolt
SP517441	Microswitch Lever Assembly
SP235119001815	Nut
SPPRI610028017	Microswitch
SP101154	Isolation Plate
SP520803	Microswitch Bracket
SP520805	Clutch
SP520808	Stop End
SP520871	Screw
SP520804	Distance Ring
SP309798500306	Bolt M3x6
SP311125000003	Washer M3
SP527728	Safety Thermostat
PRI501000069	Cable Grommet
581425	Heater 3kW/230V
581434	Heater Cover
SP311679824006	Washer M6
SP310934100006	Nut M6
SP311125240006	Washer M6
SP309933100625	Bolt M6x25
SP526439	Temperature Sensor Seal
SP311125240004	Washer M4
SP311127240004	Washer M4
SP309798524408	Bolt M4x8
SP319300006001	Hose 51.18 inch (1.3m)
SP273030000502	Hose 5x2
575487	Differential Pressure Switch
SP313250004063	Rivet
SP517238	Screw ST3.5x6.5
575488	Switch Holder
SP518623	Bolt ST4.2x9.5
SP532002	Dust Cap Humidity Sensor
SP518562	Humidity Sensor Assembly Includes items 1-6
SP309084000306	Bolt
SP311679800003	Washer
SP309798500306	Screw
SP313250004075	Rivet
SP518563	Sensor Holder

SP102456	Humidity Sensor
573395	WiFi Service kit Includes items 1-14, items 575872, 575873, 575866 and
575872	Power Supply Cable
575873	WiFi Cable
575866	Power Supply Harness Micro USB-B
573393	Control Board Holder
SP100218	Screw ST4.8x13
573392	Nut M2.5
575864	Power Supply
573394	Power Supply Holder
SP311125000003	Washer M3
SP311127000003	Washer M3
SP309084000306	Bolt M3x6
573390	Spacer M2.5x8
553442	MicroSD Card 16GB
573391	Bolt M2.5x5
553440	Control Board
SP345000626088	Binding Strip
529102	Converter USB RS485 - Nano
SP534930	Temperature Sensor
SP552675	Ventilator
SP530621	Front Panel Assembly U models; I models starting Serial No.16T014342QD;
SP559831	Front Panel Assembly I and LS350HP_PROFESSIONAL models through Serial
SP555996	Front Panel Assembly L, N, P and T models; Includes items 2-12; Gray
SP530620	Front Panel Assembly Includes items 2-12; Stainless steel
SP530623	Front Panel Assembly U models; I models starting Serial No.16T014342QD;
SP559832	Front Panel Assembly I and LS350HP_PROFESSIONAL models through Serial
SP555997	Front Panel Assembly L, N, P and T models; Includes items 2-12; Coin; Right
SP530622	Front Panel Assembly Includes items 2-12; Coin; Right door; Stainless steel
SP545543	Front Panel Assembly U models; I models starting Serial No.16T014342QD;
SP559833	Front Panel Assembly I and LS350HP_PROFESSIONAL models through Serial
SP555998	Front Panel Assembly L, N, P and T models; Includes items 2-12; Coin; Left c
SP545542	Front Panel Assembly Includes items 2-12; Coin; Left door; Stainless steel
SP309966240410	Bolt
SP515291	Coin Vault Cover Coin
SP311125000004	Washer
SP311127000004	Washer
SP515075	Bolt
SP501514	Coin Vault Frame Coin
SP524394	Coin Vault Frame Bracket Coin
SP309933240412	Bolt
SP514906	Washer
SP514530	Latch
SP524366	Washer
SP530631	Filter Panel Assembly U models; I models starting Serial No.16T014342QD; ;

SP559827	Filter Panel Assembly I and LS350HP_PROFESSIONAL models through Serial
SP555961	Filter Panel Assembly L, N, P and T models; Includes items 2-9; Gray
SP530630	Filter Panel Assembly Includes items 2-9; Stainless steel
SP530634	Filter Panel Assembly U models; I models starting Serial No.16T014342QD;
SP559828	Filter Panel Assembly I and LS350HP_PROFESSIONAL models through Serial
SP555962	Filter Panel Assembly L, N, P and T models; Includes items 2-9; With lock; G
SP530633	Filter Panel Assembly Includes items 2-9; With lock; Stainless steel
SP345900025012	Plug Not applicable for coin
SPPRI610000007	Lock
SPPRI522000012	Washer
SPPRI610001007	Lock Hook
SP521266	Chain
SP521221	Lock
SP520407	Screw
SP520408	Pin Insertion
SP560115	Control Panel Assembly U models; Includes items 1-19; Imitation stainless s
SP559884	Control Panel Assembly U models; Includes items 1-19; Stainless steel
SP560117	Control Panel Assembly I and LS350HP_PROFESSIONAL models; Includes ite
574514	Control Panel Assembly I models; Includes items 1-19; Imitation stainless st
SP559885	Control Panel Assembly I, L and N models; Includes items 1-19; Stainless ste
571930	Control Panel Assembly L and N models; Includes items 1-19; Gray; Starting
SP559883	Control Panel Assembly S models; Includes items 1-19; White; Through 12/:
SP559886	Control Panel Assembly S models; Includes items 1-19; Stainless steel
575431	Control Panel Assembly S models starting 1/1/2021; Includes items 1-19; In
SP560101	Control Panel Assembly P and T models; Includes items 1-19; Gray; L and N
SP560116	Control Panel Assembly P and T models; Includes items 1-19; Stainless steel
SP560118	Control Panel Assembly P and T models; Includes items 1-19; Black; Throug
SPPRI610000007	Lock
SP528310	Emergency Stop Knob
SP560111	Control Panel U models; Imitation stainless steel; I models starting Serial
SP560113	Control Panel I, LS350HP_PROFESSIONAL and S models; White; Through
SP560106	Control Panel L, N, P and T models; Gray
SP560114	Control Panel P and T models; Black
SP560112	Control Panel Stainless steel
SPPRI522000012	Washer
SPPRI610005007	Nut
SP528311	Emergency Stop
SP528312	Switching Unit
SP529082	Shim
SPPRI610001007	Lock Hook
SPPRI610006007	Nut
SP101275	Gasket
SP556608	Control Board I, L, N, P and T models; Gray
SP102457	Control Board S and U models; Green
SP311679800003	Washer

SP309798500306	Bolt
SP526001	Memory Empty without software version
102471	Memory Models without heat pump; Includes SP526001 Memory and EN,
102472	Memory Models without heat pump; Includes SP526001 Memory and EN,
545269	Memory Models with heat pump; Includes SP526001 Memory and EN, CZ,
545270	Memory Models with heat pump; Includes SP526001 Memory and EN, CZ,
572334	Memory Models with heat pump and frequency inverter; Includes
572335	Memory Models with heat pump and frequency inverter; Includes
SP309933240412	Bolt
SP311125000004	Washer
SP514193	Nut
SP559863	Overlay U models
SP559864	Overlay I, N and S models
SP556100	Overlay L, P and T models
SP560162	Filter Assembly Includes items 20 and 21
SP520404	Door Switch Assembly Includes items 27-34
573370	Coin Vault Assembly Includes items 1, 6, 7, 40 and 41
SP311125000004	Washer
SP517486	Rod
SP309933000416	Bolt
SP273121011001	Bushing
SP514193	Nut
SP311127000004	Washer
SP309933240412	Bolt
SP100388	Switch
SP530795	Upper Cover
SP557133	Upper Cover Single phase
SP530796	Access Cover
SP557136	Access Cover Single phase
SP100218	Screw
SP520891	Switch Panel
SPPRI404000095	Main Switch Knob
SPPRI404000097	Main Switch
SP273121013002	Bushing
SP311125000010	Washer
SP310934000010	Nut
SPPRI504000001	Adjustable Foot
SP506045	Microswitch
SP560160	Fine Filter
SP512324	Filter
SP545533	Exhaust Cover
SP545529	Bolt
SP545531	Washer
SP545530	Nut
SP518505	Front Seal

SP518719	Bolt
SP311127000003	Washer
SP311125000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP516693	Bolt
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP527801	Back Seal Models through Serial No.16T018656UH
579537	Back Seal Models starting Serial No.16T018657UH
SP309933000630	Bolt
SPPRI611000009	Spring
SP534645	Lock Hook
SP310985000006	Nut
SP321848140028	Coin Vault
573350	Coin Vault
573370	Coin Vault Assembly Includes items 18 and 19
SP309933000416	Bolt
SP273121011001	Bushing
SP530795	Upper Cover
SP530796	Access Cover
SP520890	Switch Panel
SPPRI404000095	Main Switch Knob
SP530798	Upper Rear Cover Electric models
569441	Upper Rear Cover Gas models; Also use 569448 Cover
SP100218	Screw
SPPRI404000097	Main Switch Gas and steam models
SPPRI404000098	Main Switch Electric models; 400-440V, 12 or 18 kW
SPPRI404000099	Main Switch Electric models; 208-240V, 18 kW; 400-440V, 24kW
SPPRI404000100	Main Switch Electric models; 208-240V; 24 kW
SP530799	Lower Rear Cover
SP273121013002	Bushing
SP518505	Front Seal
SP527801	Back Seal Models through Serial No.16T018656UH
579537	Back Seal Models starting Serial No.16T018657UH
SP309933000630	Bolt
SP534645	Lock Hook
SP310985000006	Nut
SPPRI611000009	Spring
SP321848140028	Coin Vault
573350	Coin Vault
SP311125000004	Washer
SP311127000004	Washer
SP309933240412	Bolt
SP100388	Switch

SP514193	Nut
SP517486	Rod
SP520404	Door Switch Assembly Includes items 1-9
SP311127000003	Washer
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP518719	Bolt
SP311127000003	Washer
SP311125000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP516693	Bolt
SP310934000010	Nut
SPPRI504000001	Adjustable Foot
SP311125000010	Washer
SP506045	Microswitch
SP512324	Filter
SP545533	Exhaust Cover
SP545529	Bolt
SP545531	Washer
SP545530	Nut
577704	Drum Assembly Galvanized; Includes items 1-7; 3000 RPM
577726	Drum Assembly Stainless steel; Includes items 1-7; 3000 RPM
SP525030	Bolt
577766	Drum Galvanized
577769	Drum Stainless steel
SP512233	Washer 1mm
517426	Washer 0.5mm
SP510697	Washer
SP311125000010	Washer
SP310934000010	Nut
573631	Nut
SP514957	Drum Cross 3000 RPM
SP534969	Glue Use with item 5
SP245704003021	Adhesive Use with item 4
SP559703	Door Assembly P and T models; S and U models through Serial No.16T0180
SP556559	Door Assembly I, L, N models; S and U models starting Serial No.16T018065
SP524359	Door Assembly L and N models; I models starting Serial No.16T014342QD; S
SP556561	Door Assembly P and T models through Serial No.16T014341QD; Heat pum
SP556558	Door Assembly P and T models through Serial No. 16T013256MB; Gas, stea
559702	Door Assembly P and T models starting Serial No. 16T013257MB; S and U n
SP534873	Door Ring
SP559701	Door P, S, T and U models; Metallic gray
SP524364	Door I, L, N, S and U models; Black
SP556552	Door P and T models; Silver

SP559705	Upper Door Hinge P, S, T and U models; Metallic gray
SP525105	Upper Door Hinge I, L, N, S and U models; Black
SP556555	Upper Door Hinge P and T models; Silver
SP520201	Stop Pin
SP512053	Door Glass
SP310934240004	Nut
SP519933	Outer Door Gasket
SP559706	Lath P, S, T and U models; Metallic gray
SP524582	Lath I, L, N, S and U models; Black
SP556553	Lath P and T models; Silver
SP559704	Lower Door Hinge P, S, T and U models; Metallic gray
SP525104	Lower Door Hinge I, L, N, S and U models; Black
SP556554	Lower Door Hinge P and T models; Silver
SP525101	Bolt
564203	Magnet
SP514530	Latch
SP524367	Bolt
SP534969	Glue Use with item 3
SP245704003021	Adhesive Use with item 7
579505	Door Assembly Gas, steam and electric models; Includes items 1-19; Black
579506	Door Assembly Gas, steam and electric models; Includes items 1-19; Metall
579507	Door Assembly Heat pump models; Includes items 1-19; Black
579508	Door Assembly Heat pump models; Includes items 1-19; Metallic gray
579509	Door Black
579510	Door Metallic gray
SP519933	Outer Door Gasket
SP512053	Door Glass
SP525105	Upper Door Hinge Black
SP559705	Upper Door Hinge Metallic gray
SP525101	Bolt
SP310934240004	Nut
SP520201	Stop Pin
SP524582	Lath Black
SP559706	Lath Metallic gray
SP525104	Lower Door Hinge Black
SP559704	Lower Door Hinge Metallic gray
SP514193	Nut
564203	Magnet Heat pump models
SP514530	Latch
SP524367	Bolt
580337	Plastic Layer Holder
SP515075	Bolt
579513	Handle Black
579514	Handle Metallic gray
SP534873	Door Ring

580339	Fixation Ring Black
579515	Fixation Ring Metallic gray
580338	Door Plastic Layer
SP309798100313	Screw
SP514127	Safety Thermostat
SP516092	Temperature Sensor
SP516669	Washer
SP528941	Heater Box
SP510984	Heating Element 6 kW
SP510985	Heating Element 4.5 kW
SP557786	Fuse
SP527900	Heating Element Bracket
SP309933000616	Bolt
SP311127000006	Washer
SP311125000006	Washer
SP520297	Plug
SP273454410020	Hose
520098	Gas Valve Wiring 60 Hertz; Use with item 18
SP310934240005	Nut
SP512130	Gas Heater Box
SP517238	Screw
SP514127	Safety Thermostat
SP512141	Electrode Bracket
SP100218	Screw
SP311125000003	Washer
SP516060	Ignition Cable
SP309933000516	Bolt
SP311127000005	Washer
SP311125000005	Washer
SP357456010080	Ignition Unit
SP516057	Flame Detection Cable
575643	Ignition Electrode
SP102018	Flange
SP514062	Flange
SP512142	Tube
SP102000	Gas Valve 50 Hertz
SP520281	Gas Valve 60 Hertz
SP512144	Valve Bracket
SPPRI202001001	Bolt
SP512067	Nozzle
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185

517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
SP512139	Cover
SP102002	Detection Electrode
SP552515	Burner Tube
SP516092	Temperature Sensor
SP516669	Washer
345000180901	Connector 50 Hertz; Use with item 18
345000160645	Contact 50 Hertz; Use with item 18
SP357500459412	Gas Valve Cable 50 Hertz; Use with item 18
SP102019	Blank Plate Kit Without regulator
571487	Ignition Cable Use with item 22
569440	Gas Heater Box
SP310934000006	Nut M6
SP311127000006	Washer M6
SP311125000006	Washer M6
577644	Stirrup M6 D1/2 inch
569444	Tube 1/2 inch
537625	Cover
572352	Elbow 1/2 inch
572351	Gas Valve
571938	Control Unit
SP309798524408	Bolt M4x8

SP311127000004	Washer M4
SP311125000004	Washer 4.3
569446	Holder
571881	Tube 1/2 inch
572350	Elbow 1/2 inch
571884	Holder
SP100218	Screw ST4.8x13
SP512139	Cover
SP517238	Screw ST 3.6x6.5
SP552515	Burner Tube
575643	Ignition Electrode
571880	Holder
SP516092	Temperature Sensor
SP516669	Washer 2 pieces
572361	Screw ST3.9x13
SP310934240005	Nut M5
SP514127	Safety Thermostat
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
575530	Orifice 330
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530

520237	Orifice 650
520236	Orifice 700
SP530409	Steam Exchanger 2 rows
SP530410	Steam Exchanger 4 rows
SP519027	Filter
SP310934240005	Nut
SP311127000005	Washer
SP311125000005	Washer
SP520227	Thermostat Bracket
SP517238	Screw
SP517236	Tube
SP405054057006	Steam Filter 3/4 inch
SP516718	Steam Valve 50 Hertz; With coil
SP514166	Steam Valve Body 60 Hertz; Without coil
SP516717	Coil 60 Hertz
SP514127	Safety Thermostat
SPPRI202001001	Bolt
SP314G00017524	Tube
SPX01140400514	Tube Insert
SP541495	Fan Holder
SP528481	Fan
SP541424	Side Panel U models; I models starting S.N.16T014342QD; S models starting
SP556649	Side Panel I and LS350HP_PROFESSIONAL models through S.N.16T014341Q
SP556005	Side Panel L, N, P and T models; Left; Gray
SP311125000004	Washer
SP311127000004	Washer
SP309084000416	Bolt
SP101415	Nut
SP541484	Fan Cover
SP101405	Bushing
SP552660	Cabinet
SP537864	Bolt
SP311902100006	Washer
SP506012	Bolt
SP551869	Humidity
SP541425	Side Panel U models; I models starting S.N.16T014342QD; S models starting
SP556650	Side Panel I and LS350HP_PROFESSIONAL models through S.N.16T014341Q
SP556007	Side Panel L, N, P and T models; Right; Gray
SP101416	Nut
SP101418	Nut
SP101408	Bushing
SP101406	Bushing
SP541494	Swivel Wheel Assembly
SP551864	Swivel Wheel Assembly
SP309933000625	Bolt

SP311679824006	Washer
SP311125000006	Washer
SP310934000006	Nut
566259	Cover Starting Serial No. 16T010067FS
SP529206	Screw M4x11
SP533726	Bolt
SP310934000020	Nut
SP541489	Base
SP541436	Bracket
SP541457	Thermostat Bracket
SP541435	Cover Models through Serial No. 16T010474FZ
SP566301	Cover Models starting Serial No. 16T010475FZ
SP551860	Cover
SP541434	Cover
SP556043	Box Assembly Includes items 1-17
SP556044	Box
SP552251	Filter
571478	Frequency Inverter
SP309084000420	Bolt
SP311127000004	Washer
SP311125000004	Washer
SP309933100625	Bolt
SP311125100006	Washer
SP310934100006	Nut
SP311679824006	Washer
SP309084000412	Bolt
SP311679800004	Washer
SP101408	Bushing
SP101416	Nut
SP101406	Bushing
SP101418	Nut
SP502214	Clip
SP556920	Nozzle Holder Assembly Includes items 6, 7, 8 and 9
581723	Time Relay For models with HP Booster
SP556947	Valve Cover Assembly
SP556959	Valve 4-way
SPPRI540000014	Hose
SP101745	Hose Pipe For water approval
SPPRI240000002	Hose Clamp
SP527236	Elbow
SP556916	Nozzle Adapter
SP556915	Nozzle Fitting Adapter
SP556919	Nozzle Bracket Assembly
SP556922	Nozzle
SP556954	Rinsing System Bracket

SP309933000616	Bolt
SP311125000006	Washer
SP311127000006	Washer
SP552666	Insulation
SP556943	Elbow Bracket Assembly
SP101416	Nut
SP101406	Bushing
SP556946	Valve Bracket Assembly
SP506012	Bolt
SP311127000004	Washer
SP311125000004	Washer
SP309084000412	Bolt
SPPRI505000054	Filling Hose Pipe
SP101621	Filling Hose Pipe For water approval
SP534910	Exhaust Assembly Includes items 1-13
SP529013	Clamp
SP144151508341	Tube
SP534914	Tube
SP273127001798	Plug
SP530689	Exhaust Bracket
SP516669	Washer
SP100218	Screw
SP534908	Bar
SP534902	Flap Assembly
SP309933000516	Bolt
SP534900	Flap Stop
SP534929	Nut
SP534904	Plug
SP528928	Tension Assembly Includes items 4, 7, 11, 14, 20 and 23-33
SP310985000006	Nut
SP311125000006	Washer
SP309933000616	Bolt
SP311125000010	Washer
SP505449	Key
SP512365	Reinforcement Bracket
SP310985000010	Nut
SP514005	Bearing
SP514012	Flange Bearing Body
SP514007	Bearing
SP309933001025	Bolt
SP518646	Double Drum Pulley
SP311902100012	Washer
SP311127000010	Washer
SP518647	Belt
SP515257	Belt

SP518649	Distance Ring
SP512366	Bearing Bracket
SP514011	Flange Bearing Body
SP310934000010	Nut
SP514483	Bearing Flange
SP311902100006	Washer
SP515517	Retaining Ring
SP326000600300	Bearing
SP534703	Double Pulley
SP534704	Tension Rod
SP309933001120	Bolt
SP311125000013	Washer
SP310985000012	Nut
SP515514	Support Plate
SP514479	Tension Assembly
SP514480	Sliding Board
SP311902100010	Washer
N/A	Motor Pulley 50 Hertz; Reversing; Refer to item 36
N/A	Motor Pulley 60 Hertz; Reversing; Refer to item 36
SP527723	Motor Pulley 50 Hertz; Nonreversing
SP528922	Motor Pulley 60 Hertz; Nonreversing
SP515418	Motor Bracket 3 Phase; Reversing
SP518517	Motor Bracket 1 Phase; Reversing
579831	Motor and Pulley 3 Phase; 50 Hertz; Reversing
579832	Motor and Pulley 3 Phase; 60 Hertz; Reversing
579834	Motor and Pulley 1 Phase; 50 Hertz; Reversing
579835	Motor and Pulley 1 Phase; 60 Hertz; Reversing
SP518556	Bolt
SP515521	Spacer
SP512363	Drive Bracket
SP309933001050	Bolt
SP523622	Fan Motor 3 phase; Nonreversing
SP523625	Fan Motor 1 phase; Nonreversing
SP520940	Spacer
SP100218	Screw
575503	Fan Housing Weldment
SP520950	Inlet Nozzle
SP309933000625	Bolt
SP311902100006	Washer
SP311902100008	Washer
SP520945	Ventilator
SP101405	Bushing
SP510954	Bolt
SP514016	Safety Thermostat
SP309798500306	Screw

SPPRI505000064	Plug
SP534930	Temperature Sensor
SP101415	Nut
SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 Phase
530518	Electric Box Cover
SP552201	Autotransformer
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP358251506220	Fuse
SP358251601312	Fuse Isolator
569857	Contactactor 208-240V 1AC
569856	Contactactor 208-240V 3AC; 380-415V 3AC+N
SP552311	Control Relay
SP506586	Relay Case Including Relay Clamp
SP346000209101	End Stop
SP514021	Transformer 208-440 Volt
SP311125000004	Washer
SP309084000410	Bolt
552482	Fuse Housing
SP345805005020	Fuse 250 Volt; T500mA
SPPRI401001021	Fuse 250 Volt; F4A
552483	End Cover
SP346000014010	Cover
SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP346000004010	Fuse Case
SP514057	Relay
569856	Contactactor
SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 Phase
569856	Contactactor
SP346000209101	End Stop
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Cont
530518	Electric Box Cover
SP358251506220	Fuse 6A
SP358251601312	Fuse Isolator
569856	Contactactor 400-440V 12kW, 18kW or 24 kW
569873	Contactactor 230V 18 kW need to use with 569856; 230V 24 kW
SP514021	Transformer 208-440 Volt
SP311125000004	Washer
SP309084000410	Bolt
552483	End Cover
552482	Fuse Housing
SP345805005020	Fuse 250 Volt; T500mA
SPPRI401001021	Fuse 250 Volt; F4A
SP346000014010	Cover
SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP346000004010	Fuse Case

SP552248	Autotransformer 440-480 Volt/50 or 60 Hertz/3 AC
530518	Electric Box Cover
SP514134	Relay 220VAC; Gas models
SP346000280402	Interconnection
SP346000209101	End Stop
569856	Contactora
SP520195	Resistance Bleeder Reversing
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP346000280101	Clamp
SP346000280301	Cover
SP514057	Relay 24VAC; Gas models
SP506586	Relay Case Gas models; Including Relay Clamp
SP514021	Transformer 14.2V plus 24V; 208-440 Volt
SP516648	Transformer 380-415 Volt without N
SP311125000004	Washer
SP309084000410	Bolt
552483	End Cover
552482	Fuse Housing
SPPRI401001021	Fuse 250 Volt F4A
SP345805005020	Fuse 250 Volt T500mA
SPPRI401020021	Fuse 1.6A
SP346000014010	Cover
SP514133	Fuse 500 Volt, F500mA; 440 Volt; 380-415 Volt
SP345805163032	Fuse 1A
SP346000004010	Fuse Case
SP557962	Frequency Inverter
SP520870	Underpressure Clutch Assembly Includes items 1-12
SP516623	Bolt
SP311125000003	Washer
SP518623	Bolt
SP517441	Microswitch Lever Assembly
SP235119001815	Nut
SPPRI610028017	Microswitch
SP101154	Isolation Plate
SP520803	Microswitch Bracket
SP520805	Clutch
SP520808	Stop End
SP520871	Screw
SP520804	Distance Ring
SP309798500306	Bolt M3x6
SP311125000003	Washer M3
SP527728	Safety Thermostat
PRI501000069	Cable Grommet
581425	Heater 3kW/230V
581434	Heater Cover

SP311679824006	Washer M6
SP310934100006	Nut M6
SP311125240006	Washer M6
SP309933100625	Bolt M6x25
SP526439	Temperature Sensor Seal
SP311125240004	Washer M4
SP311127240004	Washer M4
SP309798524408	Bolt M4x8
SP319300006001	Hose 51.18 inch (1.3m)
SP273030000502	Hose 5x2
575487	Differential Pressure Switch
SP313250004063	Rivet
SP517238	Screw ST3.5x6.5
575488	Switch Holder
SP518623	Bolt ST4.2x9.5
SP532002	Dust Cap Humidity Sensor
SP518562	Humidity Sensor Assembly Includes items 1-6
SP309084000306	Bolt
SP311679800003	Washer
SP309798500306	Screw
SP313250004075	Rivet
SP518563	Sensor Holder
SP102456	Humidity Sensor
573395	WiFi Service kit Includes items 1-14, items 575872, 575873, 575866 and Fla
575872	Power Supply Cable
575873	WiFi Cable
575866	Power Supply Harness Micro USB-B
573393	Control Board Holder
SP100218	Screw ST4.8x13
573392	Nut M2.5
575864	Power Supply
573394	Power Supply Holder
SP311125000003	Washer M3
SP311127000003	Washer M3
SP309084000306	Bolt M3x6
573390	Spacer M2.5x8
553442	MicroSD Card 16GB
573391	Bolt M2.5x5
553440	Control Board
SP345000626088	Binding Strip
529102	Converter USB RS485 - Nano
SP534930	Temperature Sensor
SP552675	Ventilator
SP528972	Front Panel Assembly Includes items 2-7; OPL; External payment system; St
SP528974	Front Panel Assembly Includes items 2-7; Coin; Right door; Stainless steel

SP545548	Front Panel Assembly Includes items 2-7; Coin; Left door; Stainless steel
528973	Front Panel Assembly I, S and U models; Includes items 2-7; OPL; External p
528975	Front Panel Assembly I, S and U models; Includes items 2-7; Coin; Right doo
545549	Front Panel Assembly I, S and U models; Includes items 2-7; Coin; Left door;
SP557169	Front Panel Assembly L, N, P and T models; Includes items 2-7; OPL; Gray; E
SP557170	Front Panel Assembly L, N, P and T models; Includes items 2-7; Coin; Right c
SP557171	Front Panel Assembly L, N, P and T models; Includes items 2-7; Coin; Left dc
SP100218	Screw
SP309966240410	Bolt
SP524366	Washer
SP514530	Latch
SP514906	Washer
519170	Sealing 4x30x2560 mm
SPPRI522000012	Washer Coin
SPPRI610001007	Lock Hook Coin
SP521221	Lock
SP520407	Screw
SP520408	Pin Insertion
SP345900025012	Plug OPL
SPPRI610000007	Lock Coin
528965	Filter Panel Assembly I, S and U models; Includes items 8-14; OPL; Imitation
528968	Filter Panel Assembly I, S and U models; Includes items 8-14; With lock; Coi
SP528964	Filter Panel Assembly Includes items 8-14; OPL; Stainless steel
SP528967	Filter Panel Assembly Includes items 8-14; With lock; Coin; OPL or External
SP557172	Filter Panel Assembly L, N, P and T models; Includes items 8-14; OPL; Gray
SP557173	Filter Panel Assembly L, N, P and T models; Includes items 8-14; With lock; (
574530	Control Panel Assembly I models; Includes items 1-15; Imitaion stainless ste
574531	Control Panel Assembly I models; Includes items 1-15; Stainless steel
575443	Control Panel Assembly S models; Includes items 1-15; Imitation stainless st
575444	Control Panel Assembly S models; Includes items 1-15; Stainless steel
575445	Control Panel Assembly U models; Includes items 1-15; Imitation stainless s
575446	Control Panel Assembly U models; Includes items 1-15; Stainless steel
571912	Control Panel Assembly L and N models; Includes items 1-15; Gray; Starting
571931	Control Panel Assembly L and N models; Includes items 1-15; Stainless steel
SP561152	Control Panel Assembly P and T models; Includes items 1-15; Gray
SP561180	Control Panel Assembly P and T models; Includes items 1-15; Stainless steel
SP528310	Emergency Stop Knob
SPPRI610000007	Lock
574532	Control Panel I, S and U models; Imitation stainless steel
SP561147	Control Panel L, N, P and T models; Gray
SP561181	Control Panel Stainless steel
SP528311	Emergency Stop Connector
SP528312	Switching Unit
SPPRI522000012	Washer
SPPRI610005007	Nut

SPPRI610001007	Lock Hook
SPPRI610006007	Nut
SP311679800003	Washer
SP309798500306	Bolt
SP526001	Memory Empty without software version
102471	Memory Includes SP526001 Memory and EN, CZ, DE, FR, NL,
102472	Memory Includes SP526001 Memory and EN, CZ, RU, SL, HR,
SP102457	Control Board S and U models; Green
SP556608	Control Board I, L, N, P and T models; Gray
SP101275	Gasket
SP556100	Overlay P and T models
SP559864	Overlay I, L, N and S models
SP559863	Overlay U models
574525	Control Panel Assembly I models; Includes items 1-26; Imitation stainless st
574528	Control Panel Assembly I models; Includes items 1-26; Stainless steel
574535	Control Panel Assembly L and N models; Includes items 1-26; Gray
574536	Control Panel Assembly L and N models; Includes items 1-26; Stainless steel
575448	Control Panel Assembly S models; Includes items 1-26; Imitation stainless st
575451	Control Panel Assembly S models; Includes items 1-26; Stainless steel
575454	Control Panel Assembly U models; Includes items 1-26; Imitation stainless s
575457	Control Panel Assembly U models; Includes items 1-26; Stainless steel
SP561149	Control Panel Assembly P and T models; Includes items 1-26; Gray
SP561183	Control Panel Assembly P and T models; Includes items 1-26; Stainless steel
557975	Extend Coin Wiring
SP557167	Control Panel L, N, P and T models; Gray
SP561162	Control Panel Stainless steel
574522	Control Panel I, S and U models; Imitaion stainless steel
SP528310	Emergency Stop Knob
SP562956	Label
SP528311	Emergency Stop Connector
SP528312	Switching Unit
SP561153	Control Bracket
SP561154	Coin Meter Bracket
SP100218	Screw
SP311125000004	Washer
SP311127000004	Washer
SP310934000004	Nut
SP309933000416	Bolt
SP559819	Control Bracket
SP102458	Control
SP311679800004	Washer
SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version

102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export France
SP521061	Cable
SP100306	Screw
SP559900	Overlay I models
SP556099	Overlay P and T models
SP559871	Overlay L, N and S models
SP559870	Overlay U models
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SPPRI610000007	Lock
SP100642	Coin Meter 1AUD + 20C
SP100866	Coin Meter 5K jeton
SP100867	Coin Meter 7K jeton
SP100868	Coin Meter 10K jeton
SP100869	Coin Meter 12K jeton
SP100870	Coin Meter 15K jeton
SP100871	Coin Meter D jeton
SP100887	Coin Meter 1pound + 20PC
SP100888	Coin Meter 1pound + 50PC
SP100891	Coin Meter 100YEN
SP100892	Coin Meter 500YEN + 100YEN
SP100895	Coin Meter 5DKK
SP100896	Coin Meter 20DKK
SP100900	Coin Meter 5ILS + 1ILS
SP100902	Coin Meter 1EUR
SP101228	Coin Meter 1 MYR
SP101535	Coin Meter 0.50EUR
SP101536	Coin Meter 0.50EUR + 1EUR
SP101797	Coin Meter 1DKK + 5DKK
SP101612	Coin Meter 10NOK + 20NOK
SP101450	Coin Meter 2DKK + 5DKK
SP101499	Coin Meter 5NOK
SP101632	Coin Meter 0.20EUR + 0.50EUR
SP101586	Coin Meter 1NZD + 2NZD
SP101155	Coin Meter 10NOK
SP102084	Coin Meter 10NT + 50NT (dolar)
SP516639	Coin Meter 2DKK
SP516638	Coin Meter Lucky Winner jeton
SP102473	Coin Meter 10 Taiwan dollar
SP516636	Coin Meter 10CZK + 20CZK
SP516804	Coin Meter 7K Equipos Par Lavar jeton

SP516737	Coin Meter 1EUR + 2EUR
SP516807	Coin Meter F10.3-W2000-19,2, Groove jeton, jeton diameter 24.8 mm
SP100898	Coin Meter 500WON
SP101437	Coin Meter 0.25USD
SP516875	Coin Meter 1AUD + 2AUD
SP102371	Coin Meter 5DKK + 10DKK
SP102407	Coin Meter 0.2EUR
SP102452	Coin Meter 1EUR + 0.2 EUR
SP102546	Coin Meter SUN WASH jeton
SP516632	Coin Meter 2DKK + 10DKK
SP516921	Coin Meter Unibel Tech 5K jeton
SP100893	Coin Meter 1AUD
SP516950	Coin Meter 1CHF
SP516967	Coin Meter 5 NOK +10NOK
SP516969	Coin Meter 1 TopMos jeton + 1BGN
516976	Coin Meter 50 penny
SP516977	Coin Meter 1 Vendo jeton
SP516980	Coin Meter 2EUR
SP516984	Coin Meter 0.05EUR
SP516991	Coin Meter 1 jeton Token
SP516994	Coin Meter 20 pence
SP516999	Coin Meter Jetons 7K + D
SP529106	Coin Meter 1 Wascator jeton diameter 22.2 mm
SP529108	Coin Meter 1 Unibel jeton diameter 18.55 mm
SP529114	Coin Meter 2EUR + 0.50EUR
529115	Coin Meter 50HUF + 100HUF
529119	Coin Meter 1 jeton, without coining, jeton diameter 20 mm
SP529124	Coin Meter 1 Volund jeton, jeton diameter 22.5 mm
534187	Coin Meter 1 Wascator jeton diameter 19 mm
529113	Coin Meter 1 Miele jeton
SP529110	Coin Meter 1 jeton without coining, jeton diameter 26 mm
534289	Coin Meter Three-groove jeton, jeton diameter 27 mm
534297	Coin Meter Three-groove jeton, jeton diameter 25 mm
537775	Coin Meter D Jeton + 2EUR
537776	Coin Meter 7K Jeton + 2EUR
SP537778	Coin Meter Milano Italy Jeton
SP537779	Coin Meter 5PLN + 1 PLN
SP537787	Coin Meter Two-groove jeton, jeton diameter 27 mm
SP537788	Coin Meter A.S.A.R.D. jeton, jeton diameter 25.8 mm
SP537825	Coin Meter 20CZK
SP537828	Coin Meter Electrolux ASARD jeton, jeton diameter 22.3 mm
SP537859	Coin Meter Laundromatic Belgium jeton, jeton diameter 22.3 mm
SP537829	Coin Meter Carsen two-groove jeton, jeton diameter 22 mm
SP537913	Coin Meter Asard Wascator jeton, jeton diameter 19.9 mm
SP552901	Coin Meter Eagle jeton, jeton diameter 25.98 mm

552951	Coin Meter 1SGD
SP552952	Coin Meter 200HUF
SP552998	Coin Meter 1TRY
SP553007	Coin Meter 0.5 MYR
553008	Coin Meter Butzi wash jeton
SP553152	Coin Meter EUROTOKEN 10 (DETON WASH)
SP556109	Coin Meter 1SGD (new Singapore dollar)
556113	Coin Meter Flash wash jeton
556114	Coin Meter 2PLN
555667	Coin Meter 50 + 50, Malaysian cents
SP556153	Coin Meter Symbol M jeton, jeton ROMAC
SP559709	Coin Meter 1 NOK + 5 NOK
560746	Coin Meter Dobi Ekspres jeton
560095	Coin Meter 5k IPSO jeton
SP560096	Coin Meter 7k IPSO jeton
560097	Coin Meter 10k IPSO jeton
560098	Coin Meter 12k IPSO jeton
560099	Coin Meter 15k IPSO jeton
SP561379	Coin Meter 10 Moroccan Dirham
SP560793	Coin Meter AAW Lav-o-seul jeton
SP564823	Coin Meter EMP500.12v5 for new SGD + new MYR + teach mode
SP553140	Coin Meter 20 CZK + 50 CZK
516848	Coin Meter Washmatic jeton
516908	Coin Meter Unibel Tech one-groove jeton
516909	Coin Meter Unibel Tech two-groove jeton
516913	Coin Meter Unibel Tech jeton for FS07
516914	Coin Meter Unibel Tech jeton for FS10
529159	Coin Meter 1 Wash Jet. 20 jeton
569920	Coin Meter 0.25USD, 1USD, 0.25CAD, 1CAD, 2CAD; Electronic EMPv7
569923	Coin Meter 0.2GBP, 0.5GBP, 1GBP, 2GBP, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569926	Coin Meter 1DKK, 2DKK, 5DKK, 10DKK, 20DKK, 1NOK, 5NOK, 10NOK, 20NOK; Electronic EMPv7
569929	Coin Meter 0.2AUD, 1AUD, 2AUD, 0.2NZD, 1NZD, 2NZD, 5HKD, 10HKD, 50HKD; Electronic EMPv7
569932	Coin Meter 1CNY, 0.1MYR, 0.2MYR, 0.5MYR; Electronic EMPv7
569935	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569938	Coin Meter 1PHP, 5PHP, 10PHP; Electronic EMPv7
569941	Coin Meter 0.1SGD, 0.2SGD, 0.5SGD, 1SGD; Electronic EMPv7
569944	Coin Meter 0.1MYR, 0.2MYR, 0.5MYR, 0.5SGD, 1SGD; Electronic EMPv7
569947	Coin Meter 1HRK, 2HRK, 5HRK; Electronic EMPv7
569950	Coin Meter 5CZK, 10CZK, 20CZK, 50CZK; Electronic EMPv7
569953	Coin Meter 0.5MAD, 1MAD, 2MAD, 5MAD, 10MAD; Electronic EMPv7
569956	Coin Meter 1PLN, 2PLN, 5PLN, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, 10ISK; Electronic EMPv7
569963	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, jeton IPSO 5K
569966	Coin Meter 0.2GBP, 0.5GBP, 1GBP, 2GBP, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569969	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, jeton G-FIS ?LAVOIR BIAN
569972	Coin Meter 0.5MYR, jeton ?DOBI PAPA?; Electronic EMPv7

569975	Coin Meter 1AUD, 2AUD, jeton ?No Cash Value?; Electronic EMPv7
569981	Coin Meter 0.5MYR, jeton ?BUBBLELAB?; Electronic EMPv7
569986	Coin Meter HAUCK 2018 jeton
572303	Coin Meter Jeton 118-16
572306	Coin Meter 1ILS, 2ILS, 5ILS, 10ILS; Electronic EMPv7
572309	Coin Meter 1ZAR, 2ZAR, 5ZAR; Electronic EMPv7
572312	Coin Meter 5RUB, 10RUB; Electronic EMPv7
572315	Coin Meter 50CLP, 100CLP, 500CLP; Electronic EMPv7
572319	Coin Meter 100JPY, 500JPY, 10TWD, 50TWD; Electronic EMPv7
572322	Coin Meter 0.5GEL, 1GEL, 2GEL; Electronic EMPv7
572325	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Jeton 7K; Electronic EMPv7
572337	Coin Meter Jeton 118-1
572338	Coin Meter Jeton 118-5
572340	Coin Meter Getton Jeton (26mm diameter x 1.7mm)
572344	Coin Meter TOKEN WH121
572360	Coin Meter 1THB, 2THB, 5THB, 10THB; Electronic EMPv7
572385	Coin Meter 0.2CHF, 0.5CHF, 1CHF, 2CHF; Electronic EMPv7
572390	Coin Meter 0.25CAD; Electronic EMPv7
579810	Coin Meter 1AED, Jeton 118-1; Electronic EMPv7
579814	Coin Meter 20HUF, 50HUF, 100HUF, 200HUF; Electronic EMPv7
579820	Coin Meter 2PLN + 5PLN; Electronic EMPv7
579864	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Jeton 118-5; Electronic EMPv7
574524	Control Panel Assembly I models; Includes items 1-24; Imitation stainless steel
574527	Control Panel Assembly I models; Includes items 1-24; Stainless steel
575447	Control Panel Assembly S models; Includes items 1-24; Imitation stainless steel
575450	Control Panel Assembly S models; Includes items 1-24; Stainless steel
575453	Control Panel Assembly U models; Includes items 1-24; Imitation stainless steel
575456	Control Panel Assembly U models; Includes items 1-24; Stainless steel
571905	Control Panel Assembly L and N models; Includes items 1-24; Gray
571932	Control Panel Assembly L and N models; Includes items 1-24; Stainless steel
SP561148	Control Panel Assembly P and T models; Includes items 1-24; Gray
SP561182	Control Panel Assembly P and T models; Includes items 1-24; Stainless steel
SP557177	Control Panel L, N, P and T models; Gray
SP561161	Control Panel Stainless steel
574521	Control Panel I, S and U models; Imitation stainless steel
SP561153	Control Bracket
SP559900	Overlay I models
SP559871	Overlay L, N and S models
SP556099	Overlay P and T models
SP559870	Overlay U models
SP309933000416	Bolt
SP311125000004	Washer
SP311127000004	Washer
SP310934000004	Nut
SP559819	Control Bracket

SP102458	Control
SP311679800004	Washer
SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version
102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export
SP521061	Cable
SP100218	Screw
SP100306	Screw
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SP528312	Switching Unit
SP528311	Emergency Stop Connector
SPPRI610000007	Lock
SP528310	Emergency Stop Knob
574526	Control Panel Assembly I models; Includes items 1-21; Imitaion stainless ste
574529	Control Panel Assembly I models; Includes items 1-21; Stainless steel
575449	Control Panel Assembly S models; Includes items 1-21; Imitation stainless st
575452	Control Panel Assembly S models; Includes items 1-21; Stainless steel
575455	Control Panel Assembly U models; Includes items 1-21; Imitation stainless s
575458	Control Panel Assembly U models; Includes items 1-21; Stainless steel
574537	Control Panel Assembly L and N models; Includes items 1-21; Gray
574538	Control Panel Assembly L and N models; Includes items 1-21; Stainless steel
SP561151	Control Panel Assembly P and T models; Includes items 1-21; Gray
SP561184	Control Panel Assembly P and T models; Includes items 1-21; Stainless steel
SP561155	Control Panel L, N, P and T models; Gray
SP561163	Control Panel Stainless steel
574523	Control Panel I, S and U models; Imitaion stainless steel
SP561153	Control Bracket
SP559900	Overlay I models
SP559871	Overlay L, N and S models
SP559870	Overlay U models
SP556099	Overlay P and T models
SP311127000004	Washer
SP309933000416	Bolt
SP311125000004	Washer
SP310934000004	Nut
SP559819	Control Bracket
SP102458	Control
SP311679800004	Washer

SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version
102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export
SP521061	Cable
SP100218	Screw
SP100306	Screw
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SPPRI610000007	Lock
573374	Coin Vault Assembly Includes items 28-32
SP520404	Door Switch Assembly Includes items 13-20
SPPRI404000097	Main Switch Gas and steam models
SPPRI404000099	Main Switch Electric models; 30 kW 380-415V or 400V; 36 kW
SPPRI404000100	Main Switch Electric models; 48 kW 380-415V or 440V
SP347700100753	Main Switch Electric models; 30 kW or 36 kW 208-240V
SP506407	Main Switch Gas models; 3ph; Neutral; 380-415V; Fourth pole
SPPRI350012007	Isolation Paper
SP520561	Door Switch Electric models
SP521104	Door Switch Gas and steam models
SP100218	Screw
SPPRI404000095	Main Switch Knob
SP309933000416	Bolt
SP311127000004	Washer
SP311125000004	Washer
SP520538	Upper Cover
SP520560	Upper Rear Cover Assembly
SP520553	Rear Cover Assembly
SP517486	Rod
SP516693	Bolt
SP311125000003	Washer
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP518719	Bolt
SP311127000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP311125000010	Washer
SP310934000010	Nut
SPPRI504000001	Adjustable Foot

SP534810	Filter Assembly
SP506045	Microswitch
SP521028	Switch Bracket
SPPRI501000071	Cable Bushing
SP515291	Coin Vault Cover
SP501514	Coin Vault Frame
SP321848140028	Coin Vault
573384	Coin Vault Support
573352	Coin Vault Case
561193	Cable Holder
SP528313	Cable Holder
SP100388	Switch
SP521036	Upper Rear Cover Electric models
SP521132	Upper Rear Cover Gas models
SP521035	Upper Rear Cover Steam models
SPPRI350000007	Terminal Board
SP310934000004	Nut
573315	Drum Assembly Galvanized; Includes items 1-7
573316	Drum Assembly Stainless steel; Includes items 1-7
SP527891	Bolt
580225	Drum Galvanized
580226	Drum Stainless steel
518508	Washer 1mm
518509	Washer 0.5mm
SP527896	Washer
SP311125000013	Washer
SP310934240012	Nut
SP525068	Trunnion
SP534969	Glue Use with item 5
SP245704003021	Adhesive Use with item 4
SP524360	Door Assembly I, L, N, S and U models; Black; Includes items 1-13
SP556563	Door Assembly P and T models; Silver; Includes items 1-13; Through Serial
572347	Door Assembly P and T models; Metallic gray; Includes items 1-13; Starting
SP534874	Door Ring
SP524365	Door I, L, N, S and U models; Black
SP556562	Door P and T models; Silver; Through Serial No. 24T009534MQ
572348	Door P and T models; Metallic gray; Starting Serial No. 24T009535MS
SP525105	Upper Door Hinge I, L, N, S and U models; Black
SP556555	Upper Door Hinge P and T models; Silver; Through Serial No. 24T009534MC
SP559705	Upper Door Hinge P and T models; Metallic gray; Starting Serial No. 24T009
SP520201	Stop Pin
SP512052	Door Glass
SP310934240004	Nut
SP525107	Outer Door Gasket
524583	Lath I, L, N, S and U models; Black

556564	Lath P and T models; Silver; Through Serial No. 24T009534MQ
572349	Lath P and T models; Metallic gray; Starting Serial No. 24T009535MS
SP525104	Lower Door Hinge I, L, N, S and U models; Black
SP556554	Lower Door Hinge P and T models; Silver; Through Serial No. 24T009534MC
SP559704	Lower Door Hinge P and T models; Metallic gray; Starting Serial No. 24T009
SP525101	Bolt
564203	Magnet
SP514530	Latch
SP524367	Bolt
SP311679824006	Washer
SP309933100625	Bolt
SP514061	Screw
SP520290	Electric Heater Box
SP521331	Cover
SP517238	Screw
SP514127	Safety Thermostat
SP516092	Temperature Sensor
SP510984	Heating Element 6 kW
SP510985	Heating Element 4.5 kW
SP557786	Fuse
SP520298	Holder
SP520297	Plug
SP516669	Washer
SP310934100006	Nut
SP273454410020	Hose
SP516144	Flame Detection Cable Use with item 24
SP516143	Ignition Cable Use with item 9
520098	Gas Valve Wiring 60 Hertz; Use with item 20
SP516669	Washer
SP522024	Gas Box Isolation
SP309798524408	Bolt
SP311127240004	Washer
SP311125240004	Washer
SP100218	Screw
SP520382	Cover
SP514127	Safety Thermostat
575643	Ignition Electrode
SP357456010080	Ignition Unit
SP311125000005	Washer
SP311127000005	Washer
SP309933000516	Bolt
SP102019	Blank Plate Kit Without regulator
SP309966240550	Bolt
SP520383	Block
SP102018	Flange

SP512142	Tube
SP520395	O-Ring
SP102000	Gas Valve 50 Hertz
SP520281	Gas Valve 60 Hertz
SPPRI202001001	Bolt
SP514062	Flange
SP512067	Nozzle
SP102002	Detection Electrode
SP520279	Electrode Bracket
SP552515	Burner Tube
SP517238	Screw
SP313250032006	Rivet
SP310934240005	Nut
SP541394	Burner Window
SP517232	Seal
SP541413	Heater Box
SP516092	Temperature Sensor
345000180901	Connector 50 Hertz; Use with item 20
345000160645	Contact 50 Hertz; Use with item 20
SP357500459412	Gas Valve Cable 50 Hertz; Use with item 20
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435

517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
571486	Ignition Cable Use with item 22
SP522024	Gas Box Isolation
SP309933240408	Screw M4
SP311127000004	Washer M4
SP311125000004	Washer M4
581445	Cover Clutch
581447	Ignition Unit Cover
SP517238	Screw ST 3.6x6.5
SP514127	Safety Thermostat
SP537625	Terminal Board Cover
571938	Control Unit
571960	Bolt M4x50
SP512142	Tube 3/4 inch
SP102018	Flange
569432	Cube
571961	Ring 22x2.5
572351	Gas Valve
569433	Holder
541395	Primary Air Limitation
SP311125240004	Washer 4.3
SP311127000004	Washer M4
SP309798524408	Bolt M4x8
575643	Ignition Electrode
571954	Electrodes Holder
SP552515	Burner Tube
SP517232	Seal
SP100218	Screw ST4.8x13
SP310934000005	Nut M5
SP541394	Burner Window
SP516669	Washer 2 pcs
SP516092	Temperature Sensor
571927	Heater Box
SP520382	Cover
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210

517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
575530	Orifice 330
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
SP273454410020	Hose
SP520390	Steam Heating Assembly
SP310934240005	Nut
SP311127000005	Washer
SP311125000005	Washer
SPPRI426001217	Pipe Nipple
SP405054057006	Steam Filter
SP516718	Steam Valve 50 Hertz; With coil
SP514166	Steam Valve Body 60 Hertz; Without coil
SP516717	Coil 60 Hertz
SP520227	Thermostat Bracket
SPPRI202001001	Bolt
SP517238	Screw
SP514127	Safety Thermostat
SP100218	Screw
SP520287	Steam Exchanger Double row
SP551784	Ventilator Assembly 1 phase; Includes items 8-15
SP551781	Ventilator Assembly 3 phase; Includes items 8-15
SP100218	Screw
SP534808	Sensor Cover
SP534930	Temperature Sensor
SP101405	Bushing
SP101415	Nut

SP527728	Safety Thermostat Electric and gas models
SP514016	Safety Thermostat Steam models
SP517238	Screw
SP523632	Ventilator
SP311127000006	Washer
SP311125000006	Washer
SP309933000620	Bolt
SP551783	Motor 1 phase
SP523622	Fan Motor 3 phase
SP510954	Bolt
SP551782	Washer
SP551779	Motor Plate
SP534809	Sensor Bracket
SP523689	Ventilator Cover
SP101863	Inlet
SP534915	Exhaust Assembly Includes items 1-10
SP100218	Screw
SP309933000516	Bolt
SP534921	Bar
SP516669	Washer
SP534929	Nut
SP534919	Plug
SP534900	Flap Stop
SP534917	Flap Stop
SP534920	Adapting Pipe
SP273127001798	Plug
SP528929	Tension Assembly Includes items 4, 7, 8, 12 and 16-27
SP514006	Bearing
SP309933001230	Bolt
SP515570	Bearing House
SP309933001025	Bolt
SP311125000010	Washer
SP521126	Bearing Bracket
SP310985000008	Nut
SP311125000008	Washer
SP309933000820	Bolt
SP521103	Distance Ring
SP530681	Double Drum Pulley
SP311902100010	Washer
SP309933001020	Bolt
SP523732	Belt
SP528925	Belt
SP326000600300	Bearing
SP515517	Retaining Ring
SP534703	Double Pulley

SP310934000010	Nut
SP534704	Tension Rod
SP309933001120	Bolt
SP520461	Tensioning Bracket
SP515514	Support Plate
SP310985000012	Nut
SP311125000013	Washer
SP514480	Sliding Board
SP311127000010	Washer
SP309916000408	Bolt
N/A	Motor Pulley 50 Hertz; Reversing; Refer to item 33
SP527724	Motor Pulley 50 Hertz; Nonreversing
SP528924	Motor Pulley 60 Hertz; Nonreversing
SP310985000010	Nut
SP309933000625	Bolt
SP311902100006	Washer
579837	Motor and Pulley 3AC; 50 Hertz; Reversing
SP520419	Motor Bracket
SP310985000006	Nut
SP521119	Bearing Bracket
SP514004	Bearing
SP505449	Key
SP520449	Bearing House
SP552248	Autotransformer
SP346000209101	End Stop
569873	Contactora 30 or 36 kW; 230V
569857	Contactora 30 or 36 kW; 380-415V; 440V
SP358251506220	Fuse
SP358251601312	Fuse Isolator
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
569856	Contactora
SP514021	Transformer
SP311125000004	Washer
SP309933240408	Bolt
552483	End Cover
552482	Fuse Housing
SP345805005020	Fuse 250V T500mA
SPPRI401001021	Fuse 250V F4A
SP346000014010	Cover
SP346000004010	Fuse Case
SP514133	Fuse 500V F500mA; 380-415V; 440V
SP528391	Transformer
SP514134	Relay 220VAC; Gas models
SP346000280402	Interconnection
SP346000209101	End Stop

569856	Contactactor
SP520195	Resistance Bleeder
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP346000280101	Clamp
SP346000280301	Cover
SP514057	Relay 24VAC; Gas models
SP506586	Relay Case Gas models; Including Relay Clamp
SP514021	Transformer 14.2V plus 24V; 208-440V
SP516648	Transformer 380-415V without N
SP311125000004	Washer
SP309933240408	Bolt
552483	End Cover
552482	Fuse Housing
SPPRI401001021	Fuse 250V F4A
SP345805005020	Fuse 250V T500mA
SPPRI401020021	Fuse 1.6A
SP346000014010	Cover
SP514133	Fuse 500V F500mA; 440V; 380-415V
SP345805163032	Fuse Gas models
SP346000004010	Fuse Case
SP557962	Frequency Inverter
SP520870	Underpressure Clutch Assembly Includes items 1-12
SP516623	Bolt
SP311125000003	Washer
SP518623	Bolt
SP517441	Microswitch Lever Assembly
SP235119001815	Nut
SPPRI610028017	Microswitch
SP101154	Isolation Plate
SP520803	Microswitch Bracket
SP520805	Clutch
SP520808	Stop End
SP520871	Screw
SP520804	Distance Ring
SP532002	Dust Cap Humidity Sensor
SP518562	Humidity Sensor Assembly Includes items 1-6
SP309084000306	Bolt
SP311679800003	Washer
SP309798500306	Screw
SP313250004075	Rivet
SP518563	Sensor Holder
SP102456	Humidity Sensor
573395	WiFi Service kit Includes items 1-14, items 575872, 575873, 575866 and
575872	Power Supply Cable
575873	WiFi Cable

575866	Power Supply Harness Micro USB-B
573393	Control Board Holder
SP100218	Screw ST4.8x13
573392	Nut M2.5
575864	Power Supply
573394	Power Supply Holder
SP311125000003	Washer M3
SP311127000003	Washer M3
SP309084000306	Bolt M3x6
573390	Spacer M2.5x8
553442	MicroSD Card 16GB
573391	Bolt M2.5x5
553440	Control Board
SP345000626088	Binding Strip
529102	Converter USB RS485 - Nano
SP528972	Front Panel Assembly Includes items 2-7; OPL; External payment system; St
SP528974	Front Panel Assembly Includes items 2-7; Coin; Right door; Stainless steel
SP545548	Front Panel Assembly Includes items 2-7; Coin; Left door; Stainless steel
528973	Front Panel Assembly I, S and U models; Includes items 2-7; OPL; External p
528975	Front Panel Assembly I, S and U models; Includes items 2-7; Coin; Right doo
545549	Front Panel Assembly I, S and U models; Includes items 2-7; Coin; Left door;
SP557169	Front Panel Assembly L, N, P and T models; Includes items 2-7; OPL; Externa
SP557170	Front Panel Assembly L, N, P and T models; Includes items 2-7; Coin; Right c
SP557171	Front Panel Assembly L, N, P and T models; Includes items 2-7; Coin; Left dc
SP100218	Screw
SP309966240410	Bolt
SP524366	Washer
SP514530	Latch
SP514906	Washer
519170	Sealing 4x30x2560 mm
SPPRI522000012	Washer Coin
SPPRI610001007	Lock Hook Coin
SP521221	Lock
SP520407	Screw
SP520408	Pin Insertion
SP345900025012	Plug OPL
SPPRI610000007	Lock Coin
528965	Filter Panel Assembly I, S and U models; Includes items 8-14; OPL; Imitation
528968	Filter Panel Assembly I, S and U models; Includes items 8-14; With lock; Coi
SP528964	Filter Panel Assembly Includes items 8-14; OPL; Stainless steel
SP528967	Filter Panel Assembly Includes items 8-14; With lock; Coin; OPL or External
SP557172	Filter Panel Assembly L, N, P and T models; Includes items 8-14; OPL; Gray
SP557173	Filter Panel Assembly L, N, P and T models; Includes items 8-14; With lock; (
574530	Control Panel Assembly I models; Includes items 1-15; Imitation stainless st
574531	Control Panel Assembly I models; Includes items 1-15; Stainless steel

575443	Control Panel Assembly S models; Includes items 1-15; Imitation stainless st
575444	Control Panel Assembly S models; Includes items 1-15; Stainless steel
575445	Control Panel Assembly U models; Includes items 1-15; Imitation stainless s
575446	Control Panel Assembly U models; Includes items 1-15; Stainless steel
571912	Control Panel Assembly L and N models; Includes items 1-15; Gray; Starting
571931	Control Panel Assembly L and N models; Includes items 1-15; Stainless steel
SP561152	Control Panel Assembly P and T models; Includes items 1-15; Gray
SP561180	Control Panel Assembly P and T models; Includes items 1-15; Stainless steel
SP528310	Emergency Stop Knob
SPPRI610000007	Lock
574532	Control Panel I, S and U models; Imitation stainless steel
SP561147	Control Panel L, N, P and T models; Gray
SP561181	Control Panel Stainless steel
SP528311	Emergency Stop Connector
SP528312	Switching Unit
SPPRI522000012	Washer
SPPRI610005007	Nut
SPPRI100010007	Hook
SPPRI610006007	Nut
SP311679800003	Washer
SP309798500306	Bolt
SP526001	Memory Empty without software version
102471	Memory Includes SP526001 Memory and EN, CZ, DE, FR, NL,
102472	Memory Includes SP526001 Memory and EN, CZ, RU, SL, HR,
SP102457	Control Board S and U models; Green
SP556608	Control Board I, L, N, P and T models; Gray
SP101275	Gasket
SP559864	Overlay I, L, N and S models
SP556100	Overlay P and T models
SP559863	Overlay U models
574525	Control Panel Assembly I models; Includes items 1-26; Imitation stainless st
574528	Control Panel Assembly I models; Includes items 1-26; Stainless steel
574535	Control Panel Assembly L and N models; Includes items 1-26; Gray
574536	Control Panel Assembly L and N models; Includes items 1-26; Stainless steel
575448	Control Panel Assembly S models; Includes items 1-26; Imitation stainless st
575451	Control Panel Assembly S models; Includes items 1-26; Stainless steel
575454	Control Panel Assembly U models; Includes items 1-26; Imitation stainless s
575457	Control Panel Assembly U models; Includes items 1-26; Stainless steel
SP561149	Control Panel Assembly P and T models; Includes items 1-26; Gray
SP561183	Control Panel Assembly P and T models; Includes items 1-26; Stainless steel
557975	Extend Coin Wiring
SP557167	Control Panel L, N, P and T models; Gray
SP561162	Control Panel Stainless steel
574522	Control Panel I, S and U models; Imitation stainless steel
SP528310	Emergency Stop Knob

SP562956	Label
SP528311	Emergency Stop Connector
SP528312	Switching Unit
SP561153	Control Bracket
SP561154	Coin Meter Bracket
SP100218	Screw
SP311125000004	Washer
SP311127000004	Washer
SP310934000004	Nut
SP309933000416	Bolt
SP559819	Control Bracket
SP102458	Control
SP311679800004	Washer
SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version
102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export France
SP521061	Cable
SP100306	Screw
SP556099	Overlay P and T models
SP559900	Overlay I models
SP559871	Overlay L, N and S models
SP559870	Overlay U models
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SPPRI610000007	Lock
SP100642	Coin Meter 1AUD + 20C
SP100866	Coin Meter 5K jeton
SP100867	Coin Meter 7K jeton
SP100868	Coin Meter 10K jeton
SP100869	Coin Meter 12K jeton
SP100870	Coin Meter 15K jeton
SP100871	Coin Meter D jeton
SP100887	Coin Meter 1pound + 20PC
SP100888	Coin Meter 1pound + 50PC
SP100891	Coin Meter 100YEN
SP100892	Coin Meter 500YEN + 100YEN
SP100895	Coin Meter 5DKK
SP100896	Coin Meter 20DKK
SP100900	Coin Meter 5ILS + 1ILS

SP100902	Coin Meter 1EUR
SP101228	Coin Meter 1 MYR
SP101535	Coin Meter 0.50EUR
SP101536	Coin Meter 0.50EUR + 1EUR
SP101797	Coin Meter 1DKK + 5DKK
SP101612	Coin Meter 10NOK + 20NOK
SP101450	Coin Meter 2DKK + 5DKK
SP101499	Coin Meter 5NOK
SP101632	Coin Meter 0.20EUR + 0.50EUR
SP101586	Coin Meter 1NZD + 2NZD
SP101155	Coin Meter 10NOK
SP102084	Coin Meter 10NT + 50NT (dolar)
SP516639	Coin Meter 2DKK
SP516638	Coin Meter Lucky Winner jeton
SP102473	Coin Meter 10 Taiwan dollar
SP516636	Coin Meter 10CZK + 20CZK
SP516804	Coin Meter 7K Equipos Par Lavar jeton
SP516737	Coin Meter 1EUR + 2EUR
SP516807	Coin Meter F10.3-W2000-19,2, Groove jeton, jeton diameter 24.8 mm
SP100898	Coin Meter 500WON
SP101437	Coin Meter 0.25USD
SP516875	Coin Meter 1AUD + 2AUD
SP102371	Coin Meter 5DKK + 10DKK
SP102407	Coin Meter 0.2EUR
SP102452	Coin Meter 1EUR + 0.2 EUR
SP102546	Coin Meter SUN WASH jeton
SP516632	Coin Meter 2DKK + 10DKK
SP516921	Coin Meter Unibel Tech 5K jeton
SP100893	Coin Meter 1AUD
SP516950	Coin Meter 1CHF
SP516967	Coin Meter 5 NOK +10NOK
SP516969	Coin Meter 1 TopMos jeton + 1BGN
516976	Coin Meter 50 penny
SP516977	Coin Meter 1 Vendo jeton
SP516980	Coin Meter 2EUR
SP516984	Coin Meter 0.05EUR
SP516991	Coin Meter 1 jeton Token
SP516994	Coin Meter 20 pence
SP516999	Coin Meter Jetons 7K + D
SP529106	Coin Meter 1 Wascator jeton diameter 22.2 mm
SP529108	Coin Meter 1 Unibel jeton diameter 18.55 mm
SP529114	Coin Meter 2EUR + 0.50EUR
529115	Coin Meter 50HUF + 100HUF
529119	Coin Meter 1 jeton, without coining, jeton diameter 20 mm
SP529124	Coin Meter 1 Volund jeton, jeton diameter 22.5 mm

534187	Coin Meter 1 Wascator jeton diameter 19 mm
529113	Coin Meter 1 Miele jeton
SP529110	Coin Meter 1 jeton without coining, jeton diameter 26 mm
534289	Coin Meter Three-groove jeton, jeton diameter 27 mm
534297	Coin Meter Three-groove jeton, jeton diameter 25 mm
537775	Coin Meter D Jeton + 2EUR
537776	Coin Meter 7K Jeton + 2EUR
SP537778	Coin Meter Milano Italy Jeton
SP537779	Coin Meter 5PLN + 1 PLN
SP537787	Coin Meter Two-groove jeton, jeton diameter 27 mm
SP537788	Coin Meter A.S.A.R.D. jeton, jeton diameter 25.8 mm
SP537825	Coin Meter 20CZK
SP537828	Coin Meter Electrolux ASARD jeton, jeton diameter 22.3 mm
SP537859	Coin Meter Laundromatic Belgium jeton, jeton diameter 22.3 mm
SP537829	Coin Meter Carsen two-groove jeton, jeton diameter 22 mm
SP537913	Coin Meter Asard Wascator jeton, jeton diameter 19.9 mm
SP552901	Coin Meter Eagle jeton, jeton diameter 25.98 mm
552951	Coin Meter 1SGD
SP552952	Coin Meter 200HUF
SP552998	Coin Meter 1TRY
SP553007	Coin Meter 0.5 MYR
553008	Coin Meter Butzi wash jeton
SP553152	Coin Meter EUROTOKEN 10 (DETON WASH)
SP556109	Coin Meter 1SGD (new Singapore dollar)
556113	Coin Meter Flash wash jeton
556114	Coin Meter 2PLN
555667	Coin Meter 50 + 50, Malaysian cents
SP556153	Coin Meter Symbol M jeton, jeton ROMAC
SP559709	Coin Meter 1 NOK + 5 NOK
560746	Coin Meter Dobi Ekspres jeton
560095	Coin Meter 5k IPSO jeton
SP560096	Coin Meter 7k IPSO jeton
560097	Coin Meter 10k IPSO jeton
560098	Coin Meter 12k IPSO jeton
560099	Coin Meter 15k IPSO jeton
SP561379	Coin Meter 10 Moroccan Dirham
SP560793	Coin Meter AAW Lav-o-seul jeton
SP564823	Coin Meter EMP500.12v5 for new SGD + new MYR + teach mode
SP553140	Coin Meter 20 CZK + 50 CZK
516848	Coin Meter Washmatic jeton
516908	Coin Meter Unibel Tech one-groove jeton
516909	Coin Meter Unibel Tech two-groove jeton
516913	Coin Meter Unibel Tech jeton for FS07
516914	Coin Meter Unibel Tech jeton for FS10
529159	Coin Meter 1 Wash Jet. 20 jeton

569920	Coin Meter 0.25USD, 1USD, 0.25CAD, 1CAD, 2CAD; Electronic EMPv7
569923	Coin Meter 0.2GBP, 0.5GBP, 1GBP, 2GBP, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569926	Coin Meter 1DKK, 2DKK, 5DKK, 10DKK, 20DKK, 1NOK, 5NOK, 10NOK, 20NOK; Electronic EMPv7
569929	Coin Meter 0.2AUD, 1AUD, 2AUD, 0.2NZD, 1NZD, 2NZD, 5HKD, 10HKD, 50HKD; Electronic EMPv7
569932	Coin Meter 1CNY, 0.1MYR, 0.2MYR, 0.5MYR; Electronic EMPv7
569935	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569938	Coin Meter 1PHP, 5PHP, 10PHP; Electronic EMPv7
569941	Coin Meter 0.1SGD, 0.2SGD, 0.5SGD, 1SGD; Electronic EMPv7
569944	Coin Meter 0.1MYR, 0.2MYR, 0.5MYR, 0.5SGD, 1SGD; Electronic EMPv7
569947	Coin Meter 1HRK, 2HRK, 5HRK; Electronic EMPv7
569950	Coin Meter 5CZK, 10CZK, 20CZK, 50CZK; Electronic EMPv7
569953	Coin Meter 0.5MAD, 1MAD, 2MAD, 5MAD, 10MAD; Electronic EMPv7
569956	Coin Meter 1PLN, 2PLN, 5PLN, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, 10ISK; Electronic EMPv7
569963	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, jeton IPSO 5K
569966	Coin Meter 0.2GBP, 0.5GBP, 1GBP, 2GBP, 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Electronic EMPv7
569969	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR, jeton G-FIS ?LAVOIR BIAN
569972	Coin Meter 0.5MYR, jeton ?DOBI PAPA?; Electronic EMPv7
569975	Coin Meter 1AUD, 2AUD, jeton ?No Cash Value?; Electronic EMPv7
569981	Coin Meter 0.5MYR, jeton ?BUBBLELAB?; Electronic EMPv7
569986	Coin Meter HAUCK 2018 jeton
572303	Coin Meter Jeton 118-16
572306	Coin Meter 1ILS, 2ILS, 5ILS, 10ILS; Electronic EMPv7
572309	Coin Meter 1ZAR, 2ZAR, 5ZAR; Electronic EMPv7
572312	Coin Meter 5RUB, 10RUB; Electronic EMPv7
572315	Coin Meter 50CLP, 100CLP, 500CLP; Electronic EMPv7
572319	Coin Meter 100JPY, 500JPY, 10TWD, 50TWD; Electronic EMPv7
572322	Coin Meter 0.5GEL, 1GEL, 2GEL; Electronic EMPv7
572325	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Jeton 7K; Electronic EMPv7
572337	Coin Meter Jeton 118-1
572338	Coin Meter Jeton 118-5
572340	Coin Meter Getton Jeton (26mm diameter x 1.7mm)
572344	Coin Meter TOKEN WH121
572360	Coin Meter 1THB, 2THB, 5THB, 10THB; Electronic EMPv7
572385	Coin Meter 0.2CHF, 0.5CHF, 1CHF, 2CHF; Electronic EMPv7
572390	Coin Meter 0.25CAD; Electronic EMPv7
579810	Coin Meter 1AED, Jeton 118-1; Electronic EMPv7
579814	Coin Meter 20HUF, 50HUF, 100HUF, 200HUF; Electronic EMPv7
579820	Coin Meter 2PLN + 5PLN; Electronic EMPv7
579864	Coin Meter 0.1EUR, 0.2EUR, 0.5EUR, 1EUR, 2EUR; Jeton 118-5; Electronic EMPv7
574524	Control Panel Assembly I models; Includes items 1-24; Imitation stainless steel
574527	Control Panel Assembly I models; Includes items 1-24; Stainless steel
575447	Control Panel Assembly S models; Includes items 1-24; Imitation stainless steel
575450	Control Panel Assembly S models; Includes items 1-24; Stainless steel
575453	Control Panel Assembly U models; Includes items 1-24; Imitation stainless steel
575456	Control Panel Assembly U models; Includes items 1-24; Stainless steel

571905	Control Panel Assembly L and N models; Includes items 1-24; Gray
571932	Control Panel Assembly L and N models; Includes items 1-24; Stainless steel
SP561148	Control Panel Assembly P and T models; Includes items 1-24; Gray
SP561182	Control Panel Assembly P and T models; Includes items 1-24; Stainless steel
SP557177	Control Panel L, N, P and T models; Gray
SP561161	Control Panel Stainless steel
574521	Control Panel I, S and U models; Imitation stainless steel
SP561153	Control Bracket
SP559900	Overlay I models
SP559871	Overlay L, N and S models
SP556099	Overlay P and T models
SP559870	Overlay U models
SP309933000416	Bolt
SP311125000004	Washer
SP311127000004	Washer
SP310934000004	Nut
SP559819	Control Bracket
SP102458	Control
SP311679800004	Washer
SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version
102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export
SP521061	Cable
SP100218	Screw
SP100306	Screw
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SP528312	Switching Unit
SP528311	Emergency Stop Connector
SPPRI610000007	Lock
SP528310	Emergency Stop Knob
574526	Control Panel Assembly I models; Includes items 1-21; Imitation stainless steel
574529	Control Panel Assembly I models; Includes items 1-21; Stainless steel
575449	Control Panel Assembly S models; Includes items 1-21; Imitation stainless steel
575452	Control Panel Assembly S models; Includes items 1-21; Stainless steel
575455	Control Panel Assembly U models; Includes items 1-21; Imitation stainless steel
575458	Control Panel Assembly U models; Includes items 1-21; Stainless steel
574537	Control Panel Assembly L and N models; Includes items 1-21; Gray
574538	Control Panel Assembly L and N models; Includes items 1-21; Stainless steel

SP561151	Control Panel Assembly P and T models; Includes items 1-21; Gray
SP561184	Control Panel Assembly P and T models; Includes items 1-21; Stainless steel
SP561155	Control Panel L, N, P and T models; Gray
SP561163	Control Panel Stainless steel
574523	Control Panel I, S and U models; Imitation stainless steel
SP561153	Control Bracket
SP556099	Overlay P and T models
SP559900	Overlay I models
SP559870	Overlay U models
SP559871	Overlay L, N and S models
SP311127000004	Washer
SP309933000416	Bolt
SP311125000004	Washer
SP310934000004	Nut
SP559819	Control Bracket
SP102458	Control
SP311679800004	Washer
SP553416	Display Board L, N, P and T models; Blue
SP560706	Display Board I models; Red
SP102459	Display Board S and U models; Green
SP526001	Memory Empty without software version
102460	Memory Includes SP526001 Memory and software
545264	Memory Includes SP526001 Memory and software, export France
SP521061	Cable
SP100218	Screw
SP100306	Screw
SPPRI610006007	Nut
SPPRI610001007	Lock Hook
SPPRI610005007	Nut
SPPRI522000012	Washer
SP311125000020	Washer
SPPRI610000007	Lock
573374	Coin Vault Assembly Includes items 28-32
SP520404	Door Switch Assembly Includes items 13-20
SPPRI404000097	Main Switch Gas and steam models
SPPRI404000099	Main Switch Electric models; 36 kW 380-415V or 440V
SPPRI404000100	Main Switch Electric models; 48 kW 380-415V or 440V
SP347700100753	Main Switch Electric models; 36 kW 208-240V
SP506407	Main Switch Gas models; 3ph; Neutral; 380-415V; Fourth pole
SPPRI350012007	Isolation Paper
SP520561	Door Switch Electric models
SP521104	Door Switch Gas and steam models
SP100218	Screw
SPPRI404000095	Main Switch Knob
SP309933000416	Bolt

SP311127000004	Washer
SP311125000004	Washer
SP520563	Upper Cover
SP520560	Upper Rear Cover Assembly
SP520553	Rear Cover Assembly
SP517486	Rod
SP516693	Bolt
SP311125000003	Washer
SP101154	Isolation Plate
SP520403	Door Switch Holder
SP518719	Bolt
SP311127000003	Washer
SP517484	Microswitch
SPPRI610011077	Microswitch
SP311125000010	Washer
SP310934000010	Nut
SPPRI504000001	Adjustable Foot
SP534810	Filter Assembly
SP506045	Microswitch
SP521028	Switch Bracket
SPPRI501000071	Cable Bushing
SP515291	Coin Vault Cover
SP501514	Coin Vault Frame
SP321848140028	Coin Vault
573384	Coin Vault Support
573352	Coin Vault Case
561193	Cable Holder
SP528313	Cable Holder
SP100388	Switch
SP521036	Upper Rear Cover Electric models
SP521132	Upper Rear Cover Gas models
SP521035	Upper Rear Cover Steam models
SPPRI350000007	Terminal Board
SP310934000004	Nut
573317	Drum Assembly Galvanized; Includes items 1-7
573318	Drum Assembly Stainless steel; Includes items 1-7
SP527892	Bolt
580227	Drum Galvanized
580228	Drum Stainless steel
518508	Washer 1mm
518509	Washer 0.5mm
SP527896	Washer
SP311125000013	Washer
SP310934240012	Nut
SP525068	Trunnion

SP534969	Glue Use with item 5
SP245704003021	Adhesive Use with item 4
SP524360	Door Assembly I, L, N, S and U models; Black; Includes items 1-13
SP556563	Door Assembly P and T models; Silver; Includes items 1-13; Through Serial No.
572347	Door Assembly P and T models; Metallic gray; Includes items 1-13; Starting Serial No.
SP534874	Door Ring
SP524365	Door I, L, N, S and U models; Black
SP556562	Door P and T models; Silver; Through Serial No.35T007230MQ
572348	Door P and T models; Metallic gray; Starting Serial No.35T007231MQ
SP525105	Upper Door Hinge I, L, N, S and U models; Black
SP556555	Upper Door Hinge P and T models; Silver; Through Serial No.35T007230MQ
SP559705	Upper Door Hinge P and T models; Metallic gray; Starting Serial No.35T007231MQ
SP520201	Stop Pin
SP512052	Door Glass
SP310934240004	Nut
SP525107	Outer Door Gasket
524583	Lath I, L, N, S and U models; Black
556564	Lath P and T models; Silver; Through Serial No.35T007230MQ
572349	Lath P and T models; Metallic gray; Starting Serial No.35T007231MQ
SP525104	Lower Door Hinge I, L, N, S and U models; Black
SP556554	Lower Door Hinge P and T models; Silver; Through Serial No.35T007230MQ
SP559704	Lower Door Hinge P and T models; Metallic gray; Starting Serial No.35T007231MQ
SP525101	Bolt
564203	Magnet
SP514530	Latch
SP524367	Bolt
SP311679824006	Washer
SP309933100625	Bolt
SP514061	Screw
SP520290	Electric Heater Box
SP521331	Cover
SP517238	Screw
SP514127	Safety Thermostat
SP516092	Temperature Sensor
SP510984	Heating Element 6 kW
SP510985	Heating Element 4.5 kW
SP557786	Fuse
SP520298	Holder
SP520297	Plug
SP516669	Washer
SP310934100006	Nut
SP273454410020	Hose
SP516144	Flame Detection Cable Use with item 24
SP516143	Ignition Cable Use with item 9
520098	Gas Valve Wiring 60 Hertz; Use with item 20

SP516669	Washer
SP522024	Gas Box Isolation
SP309798524408	Bolt
SP311127240004	Washer
SP311125240004	Washer
SP100218	Screw
SP520382	Cover
SP514127	Safety Thermostat
575643	Ignition Electrode
SP357456010080	Ignition Unit
SP311125000005	Washer
SP311127000005	Washer
SP309933000516	Bolt
SP102019	Blank Plate Kit Without regulator
SP309966240550	Bolt
SP520383	Block
SP102018	Flange
SP512142	Tube
SP520395	O-Ring
SP102000	Gas Valve 50 Hertz
SP520281	Gas Valve 60 Hertz
SPPRI202001001	Bolt
SP514062	Flange
SP512067	Nozzle
SP102002	Detection Electrode
SP520279	Electrode Bracket
SP552515	Burner Tube
SP517238	Screw
SP313250032006	Rivet
SP310934240005	Nut
SP541394	Burner Window
SP517232	Seal
SP541413	Heater Box
SP516092	Temperature Sensor
345000180901	Connector 50 Hertz; Use with item 20
345000160645	Contact 50 Hertz; Use with item 20
SP357500459412	Gas Valve Cable 50 Hertz; Use with item 20
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210

517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
571486	Ignition Cable Use with item 22
SP522024	Gas Box Isolation
SP309933240408	Screw M4
SP311127000004	Washer M4
SP311125000004	Washer M4
581445	Cover Clutch
581447	Ignition Unit Cover
SP517238	Screw ST 3.6x6.5
SP514127	Safety Thermostat
SP537625	Terminal Board Cover
571938	Control Unit
571960	Bolt M4x50
SP512142	Tube 3/4 inch
SP102018	Flange
569432	Cube
571961	Ring 22x2.5
572351	Gas Valve
569433	Holder
541395	Primary Air Limitation
SP311125240004	Washer 4.3
SP311127000004	Washer M4
SP309798524408	Bolt M4x8
575643	Ignition Electrode
571954	Electrodes Holder

SP552515	Burner Tube
SP517232	Seal
SP100218	Screw ST4.8x13
SP310934000005	Nut M5
SP541394	Burner Window
SP516669	Washer 2 pcs
SP516092	Temperature Sensor
571927	Heater Box
SP520382	Cover
525466	Orifice 130
525465	Orifice 165
517241	Orifice 170
517327	Orifice 175
517328	Orifice 185
517243	Orifice 190
517222	Orifice 200
520399	Orifice 210
517223	Orifice 215
517329	Orifice 220
517224	Orifice 235
517245	Orifice 245
530819	Orifice 250
517246	Orifice 260
517250	Orifice 290
517251	Orifice 300
517252	Orifice 310
517253	Orifice 325
575530	Orifice 330
517225	Orifice 350
517257	Orifice 360
517258	Orifice 365
517226	Orifice 380
530820	Orifice 385
517227	Orifice 420
517330	Orifice 435
517331	Orifice 445
517337	Orifice 530
520237	Orifice 650
520236	Orifice 700
SP273454410020	Hose
SP520390	Steam Heating Assembly
SP310934240005	Nut
SP311127000005	Washer
SP311125000005	Washer
SPPRI426001217	Pipe Nipple

SP405054057006	Steam Filter
SP516718	Steam Valve 50 Hertz; With coil
SP514166	Steam Valve Body 60 Hertz; Without coil
SP516717	Coil 60 Hertz
SP520227	Thermostat Bracket
SPPRI202001001	Bolt
SP517238	Screw
SP514127	Safety Thermostat
SP100218	Screw
SP520286	Steam Exchanger 4 row
SP551784	Ventilator Assembly 1 phase; Includes items 8-15
SP551781	Ventilator Assembly 3 phase; Includes items 8-15
SP100218	Screw
SP534808	Sensor Cover
SP534930	Temperature Sensor
SP101405	Bushing
SP101415	Nut
SP527728	Safety Thermostat Electric and gas models
SP514016	Safety Thermostat Steam models
SP517238	Screw
SP523632	Ventilator
SP311127000006	Washer
SP311125000006	Washer
SP309933000620	Bolt
SP551783	Motor 1 phase
SP523622	Fan Motor 3 phase
SP510954	Bolt
SP551782	Washer
SP551779	Motor Plate
SP534809	Sensor Bracket
SP523689	Ventilator Cover
SP101863	Inlet
SP534915	Exhaust Assembly Includes items 1-10
SP100218	Screw
SP309933000516	Bolt
SP534921	Bar
SP516669	Washer
SP534929	Nut
SP534919	Plug
SP534900	Flap Stop
SP534917	Flap Stop
SP534920	Adapting Pipe
SP273127001798	Plug
SP528929	Tension Assembly Includes items 4, 7, 8, 12 and 16-27
SP514006	Bearing

SP309933001230	Bolt
SP515570	Bearing House
SP309933001025	Bolt
SP311125000010	Washer
SP521126	Bearing Bracket
SP310985000008	Nut
SP311125000008	Washer
SP309933000820	Bolt
SP521103	Distance Ring
SP530681	Double Drum Pulley
SP311902100010	Washer
SP309933001020	Bolt
SP523732	Belt
SP528925	Belt
SP326000600300	Bearing
SP515517	Retaining Ring
SP534703	Double Pulley
SP310934000010	Nut
SP534704	Tension Rod
SP309933001120	Bolt
SP520461	Tensioning Bracket
SP515514	Support Plate
SP310985000012	Nut
SP311125000013	Washer
SP514480	Sliding Board
SP311127000010	Washer
SP309916000408	Bolt
N/A	Motor Pulley 50 Hertz; Reversing; Refer to item 33
SP527724	Motor Pulley 50 Hertz; Nonreversing
SP528924	Motor Pulley 60 Hertz; Nonreversing
SP310985000010	Nut
SP309933000625	Bolt
SP311902100006	Washer
579837	Motor and Pulley 3AC; 50 Hertz; Reversing
SP520419	Motor Bracket
SP310985000006	Nut
SP521119	Bearing Bracket
SP514004	Bearing
SP505449	Key
SP520449	Bearing House
SP552248	Autotransformer
SP346000209101	End Stop
569873	Contactactor 36 kW 230V; 48 kW 380-440V
569857	Contactactor 36 kW; 380-440V
SP358251506220	Fuse

SP358251601312	Fuse Isolator
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
569856	Contactactor
SP514021	Transformer
SP311125000004	Washer
SP309933240408	Bolt
552483	End Cover
552482	Fuse Housing
SP345805005020	Fuse 250V T500mA
SPPRI401001021	Fuse 250V F4A
SP346000014010	Cover
SP346000004010	Fuse Case
SP514133	Fuse 500V F500mA; 440V; 380-415V
SP528391	Transformer
SP514134	Relay 220VAC; Gas models
SP346000280402	Interconnection
SP346000209101	End Stop
569856	Contactactor
SP520195	Resistance Bleeder
569858	Mechanical Interlock Unit Need to use with 569859 Set for Reversing Conta
SP346000280101	Clamp
SP346000280301	Cover
SP514057	Relay 24VAC; Gas models
SP506586	Relay Case Gas models; Including Relay Clamp
SP514021	Transformer 14.2V plus 24V; 208-440V
SP516648	Transformer 380-415V without N
SP311125000004	Washer
SP309933240408	Bolt
552483	End Cover
552482	Fuse Housing
SPPRI401001021	Fuse 250V F4A
SP345805005020	Fuse 250V T500mA
SPPRI401020021	Fuse 1.6A
SP346000014010	Cover
SP514133	Fuse 500V F500mA; 440V; 380-415V
SP345805163032	Fuse Gas models
SP346000004010	Fuse Case
SP557962	Frequency Inverter
SP520870	Underpressure Clutch Assembly Includes items 1-12
SP516623	Bolt
SP311125000003	Washer
SP518623	Bolt
SP517441	Microswitch Lever Assembly
SP235119001815	Nut
SPPRI610028017	Microswitch

SP101154	Isolation Plate
SP520803	Microswitch Bracket
SP520805	Clutch
SP520808	Stop End
SP520871	Screw
SP520804	Distance Ring
SP532002	Dust Cap Humidity Sensor
SP518562	Humidity Sensor Assembly Includes items 1-6
SP309084000306	Bolt
SP311679800003	Washer
SP309798500306	Screw
SP313250004075	Rivet
SP518563	Sensor Holder
SP102456	Humidity Sensor
573395	WiFi Service kit Includes items 1-14, items 575872, 575873, 575866 and
575872	Power Supply Cable
575873	WiFi Cable
575866	Power Supply Harness Micro USB-B
573393	Control Board Holder
SP100218	Screw ST4.8x13
573392	Nut M2.5
575864	Power Supply
573394	Power Supply Holder
SP311125000003	Washer M3
SP311127000003	Washer M3
SP309084000306	Bolt M3x6
573390	Spacer M2.5x8
553442	MicroSD Card 16GB
573391	Bolt M2.5x5
553440	Control Board
SP345000626088	Binding Strip
529102	Converter USB RS485 - Nano